

Philips
DVD Micro Theatre

DivX

MCD177



Turn any room into a theatre

plus USB Direct playback

You're in touch with the latest and the coolest — now get a load of the hot 2-in-1 Micro Hi-Fi with DVD, WMA-CD, MP3-CD and USB Direct playback! Relax to your fave movies and music. Home entertainment will never be the same again!

Enrich your movie experience

- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Dolby Digital for ultimate movie experience

Enrich your sound experience

- View photos and listen to music directly from USB devices
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Loudness for bass and treble enhancement
- 2 x 20 W RMS/2 x 40 W music power/800 W PMPO

Easy to use

- FM digital tuning with presets
- Wake-Up and Sleep Timer

Refined in sound and look

- Elegant wood-finished speakers

PHILIPS
sense and simplicity

Highlights

USB direct

Simply plug your USB device into the system and share your stored digital music and photos with your family and friends.

Digital Sound Control



Digital Sound Control offers you a choice of preset Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Loudness for bass and treble

In the sound spectrum, high and low frequencies are relatively less audible to human ears - especially at low volumes. With the Loudness feature activated, the bass and treble will be amplified so you can savour a more balanced sound perception overall.

Dolby Digital

Because Dolby Digital standards, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.



Specifications

Sound

- Output Power: 2x20 W RMS/2x40 W music power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost, Loudness
- Sound System: Dolby Digital

Loudspeakers

- Main Speaker: 4" woofer, Bass Reflex Speaker System

Video Playback

- Playback Media: DVD-Video, Picture CD, Video CD/SVCD, DivX, DVD+R/+RW, DVD-R/-RW
- Disc Playback Modes: A-B Repeat, Angle, PBC, Slow Motion, Zoom, Parental control, Disc Menu, Fast Reverse, Fast Forward, OSD
- DVD Region: 2

Still Picture Playback

- Picture compression format: JPEG
- Picture enhancement: Slideshow with MP3 playback
- Playback Media: CD-R/RW, DVD+R/+RW, Picture CD

Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play, Fast Forward/Reverse, Next/Previous Track Search
- Loader Type: Top
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

Tuner/reception/transmission

- Auto digital tuning
- Station presets: 20
- Tuner Bands: FM Stereo
- Tuner Enhancements: Auto Store

Connectivity

- Video Output - Analogue: Composite CVBS (yellow cinch), S-Video (on Hosiden), SCART
- Other connections: Digital audio coaxial out, FM Antenna
- Headphones: 3.5 mm
- Audio Connections: 3.5mm Line in, Analogue Audio Out (L/R)
- USB: USB host

Convenience

- Display Type: LCD
- OSD Languages: English, Dutch, French, German, Italian, Portuguese, Spanish, Swedish, Russian, Turkish
- Alarms: CD Alarm, Radio Alarm, Sleep timer, USB alarm
- Clock: On main display
- Eco Power Standby: 1 watt
- Backlight colour: Blue

Accessories

- Included Accessories: Composite video cable (Y), FM antenna, World Wide Warranty leaflet
- Remote control: 40-key with Lithium batteries
- Quick start guide: English, German, Dutch, French, Spanish, Italian
- User manual: 16 languages
- AC/DC adapter: Switching power supply

Dimensions

- Set dimensions (W x H x D): 232 x 85 x 275 mm
- Main speaker dimensions (W x H x D): 160 x 250 x 180 mm
- Packaging dimensions (W x H x D): 554 x 405 x 225 mm
- Weight incl. Packaging: 6.9 kg

Power

- Power supply: 100-240 VAC, 50/60 Hz



Issue date 2009-03-13

Version: 2.0.5

12 NC: 8670 000 35812
EAN: 87 12581 38532 3

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com