

Philips docking speaker with Bluetooth®

for iPod/iPhone



AD620

Music set free wirelessly via Bluetooth

Groove to smooth tunes from your iPod and iPhone. This Philips Docking speaker offers powerful bass with Bass Reflex Speaker System. Stream music wirelessly via Bluetooth, or dock your iPod or iPhone.

Crystal clear sound

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Shielding technology to block mobile phone interference
- 20W RMS total output power

Enjoy your favorite music

- Play and charge your iPod/iPhone simultaneously
- MP3 Link for portable music playback

Advanced versatility

- Bluetooth wireless music streaming from iPod/iPhone
- Dock any iPod/iPhone, even in its case



4D620/05

Specifications

iPod compatibility

· Compatible with: iPod classic, iPod mini, iPod nano 1st generation, iPod nano 2nd generation, iPod nano 3rd generation, iPod nano 4th generation, iPod nano 5th generation, iPod nano 6th generation, iPod touch, iPod touch 2nd generation, iPod touch 3rd generation, iPod touch 4th

iPhone compatibility

Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4, iPhone 4S

Sound

- Output power (RMS): 20W
- · Sound System: Stereo
- Volume Control: Volume Control up/down

Loudspeakers

• Speaker Drivers: 2 x 2.25" full range woofers







Connectivity

- Bluetooth version: 2.1
- Bluetooth profiles: A2DP
- Bluetooth range: line of sight, 10M or 30FT
- MP3 Link: 3.5mm stereo line in

Accessories

· AC/DC adaptor

Dimensions

- Product dimensions (WxDxH): 275 x 121 x 117
- Packaging dimensions (WxDxH): 361 x 133 x 148
- Product weight: 1.2 kg
- Weight incl. Packaging: 1.7 kg

Power supply: 100-240VAC, 50/60Hz

Highlights

Bluetooth music streaming

Bluetooth is a short range wireless communication technology that is both robust and energy-efficient. The technology allows easy wireless connection to other Bluetooth devices, so you can play your favorite music from your iPod or iPhone on your Philips audio system - conveniently, anytime you

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

Dock iPod/iPhone in its case



Smartly designed spring-loaded docking port effortlessly accommodates any iPod or iPhone, without special adaptors. What's more, it works even when most protective cases are on - just dock your iPod or iPhone as it is. Now you can truly have fuss-free enjoyment of your music.



Issue date 2017-04-05

Version: 2.0.6

12 NC: 8670 000 89496 EAN: 87 12581 64256 3 © 2017 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com