

Philips  
CD Soundmachine

MP3

AZ1839



## Enjoy great sound wherever you go

Want to access your music collection on your portable music player without using headphones? Simply plug the player into the USB Direct socket of the Philips CD Soundmachine AZ1839 and enjoy your digital tunes through powerful speakers.

### **Powerful sound you can hear and feel**

- Bass Reflex Speakers for a deep, powerful sound
- 4" full range speakers for powerful sound
- Dynamic Bass Boost for deep and dramatic sound
- 2x1W RMS total output power

### **Multisource music enjoyment**

- USB Direct for MP3/WMA music playback
- Play MP3/WMA-CD, CD and CD-RW
- FM/MW stereo tuner

### **Easy to use**

- MP3 Link for portable music playback
- Stereo headphone socket

# PHILIPS

# Specifications

## Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Programmable Tracks: 20

## Connectivity

- USB: USB host
- Headphone: 3.5 mm
- 3.5mm stereo line in: MP3 LINK

## Tuner/Reception/Transmission

- Antenna: FM Antenna
- Tuner Bands: FM, MW

## Sound

- Output power (RMS): 2X1W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Speaker diameter: 4"
- Volume Control: rotary
- Loudspeaker types: Bass Reflex Speaker System

## Loudspeakers

- Built-in speakers: 2
- Finishing: Metal
- Loudspeaker types: Loudspeakers

## Convenience

- Display Digits: 3
- Display Type: LCD

## Accessories

- Included Accessories: AC Power Cord, Warranty certificate, 3.5mm stereo line in cable
- User Manual: English & Korean

## Dimensions

- Product dimensions (W x H x D): 420 x 168 x 240 mm
- Packaging dimensions (W x H x D): 457 x 283 x 210 mm
- Weight: 2.8 kg
- Weight incl. Packaging: 3.8 kg

## Power

- Battery type: LR20
- Battery voltage: 1.5 V
- Mains power: 220 - 240V, 50/60Hz
- Number of batteries: 6

# Highlights

## USB Direct-MP3/WMA

With the USB Direct mode, you can simply select the music on a USB device and playback all your content. All you have to do is plug in your USB device to playback music or export content from the device.

## Bass Reflex Speakers

Bass Reflex Speakers delivers a deep bass experience. Differ from conventional loudspeakers, the addition of a bass pipe that is acoustically aligned to the woofer optimizes the low frequency roll-off. The result is a deep controlled bass and low distortion. Combined with the response of the woofer, it extends the overall low frequency sounds to create a whole new dimension of deep bass.

## MP3 Link for portable music

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.



Issue date 2014-12-03

Version: 1.0.2

12 NC: 8670 000 51171  
EAN: 87 12581 47462 1

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Avoid extensive use of the set in a volume higher than 85 decibel because this may damage your hearing.