



Philips
Original Boombox

Bluetooth®
FM
USB dock for play/charging
12 W



OST690



Music from your smartphone wirelessly

with this boombox

The eighties are back! This retro-style boombox not only has looks that kill but also plays music better. Bluetooth streaming, audio line-in and USB direct give all the options you need, along with USB charging and a built-in compartment for storage

Enjoy your music wirelessly

- Stream your music library via Bluetooth

Enjoy your music from different sources

- Enjoy MP3/WMA music directly from your portable USB drives
- FM digital tuning
- Audio-in for easy portable music playback

Easy to use

- Built-in compartment for charging your Smartphone

Rich and clear sound

- 12 W total output power
- Dynamic Bass Boost for deep and dramatic sound

PHILIPS

Original Boombox
Bluetooth® FM, USB dock for play/charging, 12 W

Highlights

Stream your music library
Stream your music library via Bluetooth

FM digital tuning



FM digital tuning

AUDIO-IN (3.5 mm)



Make one easy connection and enjoy all your music from portable devices and computers. Simply plug your device into the AUDIO-IN (3.5 mm) port on your Philips set. With computers, the connection is typically made from the headset output. Once linked, you can enjoy your entire music collection directly, on a set of superior speakers. Philips simply delivers better sound.

USB Direct for MP3/WMA music



Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favourite moments with family and friends.

Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



OST690/10

Specifications

Bluetooth® wireless technology

- Version: BT 2.1
- Profiles: A2DP, AVRCP

Audio Playback

- Bluetooth mode: Play/Pause, Previous/Next
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle
- Programmable Tracks: 20

Connectivity

- USB: USB host
- Audio in (3.5 mm)

Tuner/Reception/Transmission

- Antenna: FM antenna
- Tuner bands: FM
- Station presets: 20
- Tuner enhancement: auto digital tuning

Sound

- Sound enhancement: bass reflex system, Dynamic Bass Boost
- Output Power: 12 W max.
- Sound System: Stereo
- Volume control: rotary (digital)

Loudspeakers

- Built-in speakers: 2
- Speaker diameter: 4"

Convenience

- Display Type: LED
- Display Enhancements: Brightness Control

Accessories

- Power cord
- User Manual: multi-lingual
- Warranty: Warranty leaflet

Power

- Number of batteries: 6 x LR14/C-cell (not included)
- Mains power: 220-240 V 50/60 Hz

Dimensions

- Packaging depth: 146 mm
- Packaging height: 275 mm
- Packaging width: 510 mm
- Weight incl. Packaging: 3.3 kg
- Weight: 2.3 kg
- Main unit depth: 146 mm
- Main unit height: 275 mm
- Main unit width: 447 mm



Issue date 2016-04-25

Version: 4.0.7

12 NC: 8670 001 00385
EAN: 08 71258 16783 26

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com