

Philips
DVD Micro Theatre

MCD183



Enjoy great movie experience

with USB Direct playback

Be assured of cinematic room-filling sound with the Philips DVD micro theatre MCD183. The speaker system backed with 100 W RMS total output power allows you to feel every sound effect. Also features USB Direct for photo and music playback.

Enrich your movie experience

- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Dolby Digital for ultimate movie experience
- Progressive Scan component video for optimised image quality

Enrich your sound experience

- View photos and listen to music directly from USB devices
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Total 100 W RMS

Start the day your way

- Wake-Up and Sleep Timer
- Digital tuning with 20 pre-set stations for extra convenience

PHILIPS

Highlights

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of

the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

USB Direct plays photos/music

Simply plug your USB device into the system and share your stored digital music and photos with your family and friends.

Play DVD, DivX and MP3/WMA-CD

The Philips player is compatible with most DVD and CD discs available in the market. DVD, DivX®, (S)VCD, MP3/WMA-CD, CD(RW) and Picture CD - all of them can play on the player. SVCD stands for "Super VideoCD". The quality of a SVCD is much better than a VCD, with a much sharper picture, because of the higher resolution. With DivX® support, you are able to enjoy DivX® encoded videos. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs.



Specifications

Sound

- Output Power: 2 x 25 W + 50 W RMS/1800 W PMPO
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost
- Sound System: Dolby Digital
- Output power (RMS): 100 W

Loudspeakers

- Main Speaker: 3" woofer
- Subwoofer type: Passive

Video Playback

- Playback Media: DVD+RW, DVD-Video, Picture CD, Video CD/SVCD, DivX, DVD, DivX Ultra
- Disc Playback Modes: Angle, PBC, Slow Motion, Zoom, OSD, Resume Playback from Stop, Parental control, A-B Repeat
- DVD Region.: 2
- Video Enhancement: Progressive Scan

Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/programme, Shuffle Play
- Loader Type: Tray
- Number of Discs: 1
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Repeat, Shuffle, Stop

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Station presets: 20
- Tuner Enhancements: Auto Store

Connectivity

- Video Output - Analogue: Component Y Pb Pr (cinch), Composite CVBS (yellow cinch), S-Video (on Hosiden), SCART
- Other connections: FM Antenna, Line out
- 3.5 mm stereo line in: MP3 Link
- Audio Connections: RCA Aux in
- USB: USB host

Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm
- Clock: On main display
- Display Type: LCD

Accessories

- Included accessories: Composite video cable (Y), FM antenna, AC Power Cord, IFU/User Manual, Quick Use Guide, World Wide Warranty leaflet
- Remote control: 38-key with Lithium battery
- Cables: MP3 line-in cable

Dimensions

- Set dimensions (W x H x D): 200 x 125 x 270 mm
- Main speaker dimensions (W x H x D): 135 x 255 x 150 mm
- Packaging dimensions (W x H x D): 545 x 314 x 350 mm
- Subwoofer dimensions (W x H x D): 160 x 255 x 250 mm
- Weight incl. Packaging: 8.5 kg

Power

- Power supply: 220-240 V



Issue date 2013-05-10

Version: 2.0.7

12 NC: 8670 000 50834
EAN: 87 12581 47260 3

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com