

Philips
Micro Hi-Fi System

DAB radio
Compact design

MCB146



Enjoy crystal clear sound from DAB radio

Enjoy superb clarity with built-in DAB tuner with this Micro system. The MC146 Micro System will enhance your living space while enriching your music listening experience. Just press Play to enjoy room-filling, dynamic bass sounds.

Enjoy digital quality DAB radio

- DAB and FM compatible for a complete radio experience
- Tune into digital-quality radio stations

Enrich your sound experience

- Play CD, CD-R and CD-RW discs
- Dynamic Bass Boost for deep and dramatic sound
- 4 W RMS total output power

Easy to use

- Wake-up and sleep timer functions
- Digital tuning with 20 pre-set stations for extra convenience

Fits any space, any lifestyle

- Compact design
- Easy-to-use remote control included

PHILIPS

Specifications

Sound

- Output Power: 2 x 2 W RMS/2 x 4 W music power
- Volume Control: Volume Control up/down
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo

Loudspeakers

- Main Speaker: 3" woofer

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/programme, Shuffle Play, Fast Forward/Reverse, Next/Previous Track Search, Repeat Play
- Loader Type: Top
- ID3-tag support

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 20
- DAB: Band III, Info display, Menu, Smart Scan
- RDS: Programme Type, Radio Text, Station Name
- Tuner Enhancements: Auto Store

Connectivity

- Headphones: 3.5 mm
- Other connections: MW Antenna, Fixed FM and

- DAB T-shape antenna
- Audio Connections: 3.5 mm Line in

Convenience

- Alarms: Sleep timer, CD Alarm, Radio Alarm
- Clock: On main display
- Display Type: LCD
- Backlight colour: Blue
- Backlight
- Eco Power Standby: 1 watt

Accessories

- Included accessories: FM/MW Antenna, World Wide Warranty leaflet, DAB antenna
- Remote control: 24-key with battery
- Quick start guide: English
- User Manual: English

Dimensions

- Set dimensions (W x H x D): 148 x 233 x 216 mm
- Main speaker dimensions (W x H x D): 134 x 230 x 152 mm
- Packaging dimensions (W x H x D): 370 x 270 x 326 mm
- Weight incl. Packaging: 4.75 kg

Power

- Power supply: 220-240 V, 50 Hz

Highlights

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

DAB and FM compatible

DAB (Digital Audio Broadcasting) digital radio is a new way of broadcasting radio, in addition to FM analogue transmission, via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear, crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can find. With DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no retuning on the move.



Issue date 2016-10-06

Version: 1.0.8

12 NC: 8670 000 38927
EAN: 87 12581 41179 4

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com