Philips Portable DVD Player with Zero Bright Dot™ screen

25.9 cm (10.2") widescreen LCD



PET1002



The ultimate DVD experience

With high-resolution 25.9 cm (10.2") LCD display

Pure entertainment on the go! PET1002's high-resolution 25.9 cm (10.2") LCD screen with Philips Zero Bright Dot[™] ensures optimal screen quality. Easily enjoy up to 5 hours' non-stop playback of DVDs, DivX®, MPEG4 movies and MP3/WMA-CD music.

Immerse yourself in AV entertainment on the go

- Play DVD, DVD+/-R and DVD+/-RW, (S)VCD, DivX® and MPEG4 movies
- Enjoy MP3/WMA-CD, CD and CD-RW music
- Share JPEG image files with Picture CD

Perfect viewing anywhere

- Zero Bright Dot[™] screen for optimal screen quality
- High-resolution 10.2" TFT LCD display for great viewing
- Enjoy movies in 16:9 widescreen format
- Built-in quality stereo speakers

For ultimate convenience

- Sleek, premium design
- Enjoy up to 5 hours' continuous playback*
- Big screen viewing with S-Video and Component Video output
- Car adapter and slim remote control
- Share entertainment fun with dual headphone jacks





PET1002/05

Highlights

Play DVD, DivX and MPEG4

With DivX® support, you are able to enjoy DivX® encoded videos in the comfort of your living room. The DivX® media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/ RW, memory cards and DVD-video. DivX® CDs can be played back on selected DVD players, DVD Recorders and Home Theatre Systems.

Zero Bright Dot[™] screen

Enjoy highest-quality images that are free from annoying blank spots on the LCD screen. LCD displays commonly have imperfections, termed 'bright dots' by the LCD industry. A limited number of bright dots was once considered an inevitable side effect of LCD mass production. With Philips' strict quality control procedures used for our Portable DVD Players, our LCD displays are produced with zero tolerance for bright dots. Select Portable DVD Players come with Philips Zero Bright Dot[™] Policy to guarantee optimal screen quality.















Specifications

Picture/Display

- Display screen type: LCD TFT
- LCD panel type: Anti-glare polariser
- Diagonal screen size (inch): 10.2 inch
- Resolution: 800(w) x 480 (H) x 3 (RGB)
- Brightness: 200 cd/m²
- Contrast ratio (typical): 250:1
- Effective viewing area: 222.0 X 133.2 mm
- Pixel pitch: 0.2775 (w) x 0.0.2775 (H) mm
- Response time (typical): 30 ms

Sound

• Output Power: 250 mW RMS (built-in speakers)

- Output power (RMS): 10 mW RMS (earphone)
- Signal to noise ratio: >80 dB (earphone), >62 dB (built-in speakers)

Video Playback

- Playback Media: DVD, Picture CD, SVCD, Video CD, DVD-R/-RW, DVD+R/+RW, CD-R/CD-RW
- Compression formats: MPEG4, Divx
- Disc Menu, Fast Reverse, Fast Forward, Repeat, Shuffle Play, Slow Reverse, Slow Forward, Zoom
- Video disc playback system: NTSC, PAL

Audio Playback

- · Compression format: Dolby Digital, MP3, WMA
- Playback Media: MP3-CD, CD, CD-R, CD-RW, WMA-CD
- File systems supported: ISO-9660, Jolliet
- MP3 bit rates: 32 320 kbps
- WMA bit rates: 32 192 kbps

Connectivity

- AV output: Composite (CVBS) x 1
- AV input: Composite (CVBS) x 1
- Audio Output Digital: Coaxial (cinch)
- DC in: 9 V
- Other connections: S-Video out, Component Video out Interlaced
- Headphone jack: 3.5 mm Stereo Headphone x 2

Г1002/05

- Convenience
- Shock proof
- Battery charging indication

Accessories

- Battery pack: AY4384, 7.4 V, Li-ion rechargeable batteries
- AC/DC Adapter: ADPV18A (110–240 v, 50/60 Hz)
- Car kit: cigarette outlet adapter, 12vDC
- Remote control: RC810 (credit card style, 38 keys) • Cables: A/V cable x 1, S-video cable x 1,
 - Component video cable x 1
- User Manual: English/French/German/Spanish
- · Included accessories: Travel pouch

Dimensions

- Master carton dimensions: 527 x 295 x 437 mm
- Master carton quantity: 3
- Packaging dimensions (W x H x D):
- 392 x 156 x 258 mm • Product dimensions (W x H x D):
- 260 x 30 x 180 mm
- Product weight: 1.2 kg
- Packaging type: D-box



Issue date 2012-01-22

© 2012 Koninklijke Philips Electronics N.V. All Rights reserved.

Electronics N.V. or their respective owners.

Version: 2.0.8

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips

* Rechargeable batteries have a limited number of charge cycles and may eventually need to be replaced. Battery life and number of charge cycles vary by use and settings.

Battery life varies by use and settings. Windows Media and the Windows logo are trademarks or

registered trademarks of Microsoft Corporation in the United States and/or other countries.

DivX, DivX Certified and associated logos are trademarks of DivXNetworks, Inc. and are used under licence.

12 NC: 9073 101 02396 EAN: 87 10895 94139 6 www.philips.com

• Disc Playback Modes: OSD, A-B Repeat, Angle,