



## The full cinematic sound experience

### Superb audio & video performance


- 6 channel full digital Class D™ Amplifier
- DTS, Dolby Digital 5.1 and Dolby Pro Logic II
- Wide Spectrum Speaker System
- Progressive Scan for razor-sharp and flicker-free images

### Plays practically any disc format

- Movies: DVD, DVD+R, DVD+RW, VCD, SVCD
- Music: CD, MP3-CD, CD-R, CD-RW
- Pictures: Picture CD (JPEG) with music (MP3)

### Quick, clean & easy set-up

- 3-step easy set-up
- Color-coded Easy-Fit™ connectors
- Dual orientation subwoofer



# Compact DVD Home Entertainment System

## standard product information



### Playback formats

- Video: DVD, DVD+R/RW, VCD, SVCD
- Audio: CD, CD-R/RW, MP3-CD\*
- Pictures: Picture-CD (JPEG) with music (MP3\*)

\* Plays MP3-CD (supports 32, 56, 64, 96, 128, 256 kbps and variable bit rate)

### DVD functionality

- Multi-angle functionality
- Audio selection
- Parental control
- Repeat track/disc/A-B
- Program, Resume, Zoom, Slow

### Receiver functionality

- Rock, Digital, Jazz, Classic, Drama, Action, Sci-Fi, Concert
- Dolby Digital, DTS and Dolby Pro Logic II
- Class D™ Amplifier for high quality audio performance

### Tuner (radio)

- FM/MW Digital tuning with 20 presets and automatic installation

### Amplifier

- 6 x 50 watts RMS
- 6 x 600 watts PMPO
- 3600 watts PMPO

### Loudspeaker boxes

- Magnetically shielded front and center
- 4 Two-way satellite speakers (L, R, SL, SR)
  - Frequency Range: 120Hz~20kHz
  - Impedance: 4 Ω
  - Drivers: 3" full-range woofer  
1" piezo
- Two-way Center speaker
  - Frequency Range: 120Hz~20kHz
  - Impedance: 4 Ω
  - Drivers: 2 x 3" full-range woofer  
1" piezo

- Subwoofer with horizontal/vertical option for flexible installation

- Frequency Range: 30Hz~120Hz
- Impedance: 4 Ω
- Drivers: 6.5" high efficiency woofer

### Connections

- Audio input:
  - analog :AUX
  - digital : 1 x cinch
- Audio output:
  - analog : Line out (cinch)
  - digital : 1 x cinch
- Video output:
  - CVBS (Yellow cinch)
  - S-Video (Hosiden)
  - Component video (Y, Pb, Pr)
- Antenna : FM coax, MW loop
- Speakers : socket connectors

### Video performance

- Progressive Scan : NTSC
- Video decoding : MPEG-2/MPEG-1
- Video format : 4:3 / 16:9
- Video System : PAL/NTSC
- Video DAC : 12 bit

### Audio performance

- Audio DAC : 24 bit, 192 kHz
- Signal to Noise ratio (1kHz) : >95 dB
- Frequency response : 30 Hz - 20 kHz

### Power supply

- Power requirement: 220-230V, 50Hz (75, 93)  
110-240V, 50-60Hz (169, 178)
- Power consumption: 80 watts
- Eco power standby: <2 watts

### General

- 45 keys Remote Control
- Local and On Screen Display

### Class D™ Amplifier


With up to 95% efficiency, Class D Digital Amplifiers mark a huge advance over traditional AB type amplifiers, resulting in high-powered pure and digital sound quality.

### Dolby Pro Logic II

Dolby Pro Logic II brings out the hidden spatial cues in all existing music recordings in a natural, convincing way. Dolby Pro Logic II decoding lets you transform Dolby Surround and stereo courses - including music - into convincing 5.1 sound for powerful and realistic music and home theater sound.

### Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending field with the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A flicker-free high resolution image is created giving you the best viewing.



(graphics to be finalised)

### physical info

#### EAN codes

87 10895 79495 4 (169) 87 10895 80649 7 (78)  
87 10895 80647 3 (75) 87 10895 80650 3 (93)

#### Dimensions

Product:  
- DVD System: 360mm W x 54mm H x 316mm D  
- Surround speaker: 89mm W x 162mm H x 70mm D  
- Center speaker: 234mm W x 96mm H x 70mm D  
- Subwoofer: 220mm W x 230mm H x 360mm D

Package: 399mm W x 412mm H x 460mm D

Weight (approx):  
- DVD System: 2.90 kg - Surround speaker: 0.44 kg  
- Center speaker: 0.94 kg - Subwoofer: 4.50 kg  
- Carton: 12.3 kg

#### Bundled Equipment

• DVD Receiver System • 2x front satellite speakers • 1x centre speaker  
• 2x surround speakers • 1x subwoofer • AC power cable • FM antenna  
• MW Loop antenna • Multi-function remote control (Zappa Plus) • 2x AA batteries • User Manual • Quick Use Guide

Printed in Singapore, December 2003  
Specifications subject to change without notice © 2003 Koninklijke Philips Electronics N.V.  
All rights reserved.

www.philips.com

