



Philips
Power strip

7 outlets
15ft
yellow-black

SPS2060B



Great for the workshop

Expand your number of outlets

Constructed with the Do-it-yourself and the light contractor in mind, this power strip features an on/off switch with built in 15amp circuit breaker, cable management and 15' power cord. It is ideal for use indoors or in the garage.

Dependable protection

- Master on/off switch
- 15 amp circuit breaker

Built-in convenience

- 7 outlets
- Heavy Duty 15ft 14/3 cord
- 1 adapter spaced outlet
- Built in cord management
- Built in Key hole slots for mounting

PHILIPS

Power strip
7 outlets 15ft, yellow-black

SPS2060B/17

Specifications

Packaging dimensions

- Number of products included: 1
- Packaging dimensions (W x H x D): 5.5 x 16.5 x 1.6 inch
- Nett weight: 2.436 lb
- Gross weight: 2.502 lb
- Tare weight: 0.066 lb
- UPC: 6 09585 19969 9
- Packaging type: Carton

Outer Carton

- Number of consumer packagings: 3
- Outer carton (L x W x H): 16.6 x 6.0 x 6.1 inch
- Nett weight: 7.308 lb
- Gross weight: 8.245 lb
- Tare weight: 0.937 lb
- GTIN: 1 06 09585 19969 6

Highlights

Master on/off switch

This master switch controls power to the outlets on the power multiplier

15 amp circuit breaker

Safeguards against overburdening the power multiplier by sensing when the connected equipment is drawing more electricity than the power multiplier can handle. It then disconnects from the power, guarding against electrical fires.

7 outlets

Converts one outlet into seven outlets allowing you to plug in multiple devices from one single AC outlet.

Heavy Duty 15ft 14/3 cord

A Heavy Duty power cord that is design to extend the outlet away from the wall

1 adapter spaced outlet

An outlet that is designed to accommodate electrical adapters or oversized plugs due to the amount of space around it

Cord Management

A cord management device that allows the cable/cords to be routed in the same direction for a more organized appearance

Key Hole Mounting

Key Holes can be used to mount the unit directly to the wall by placing them over the screw heads and lowering into place



Issue date 2014-03-14

Version: 1.0.5

12 NC: 8670 000 69827
UPC: 6 09585 19969 9

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com