

Philips
Micro Hi-Fi System

DAB radio
USB Direct
Compact design

MCB279



Enjoy crystal clear sound from DAB radio

with USB direct and CD ripping

Enjoy superb clarity with built-in DAB tuner with this Micro system. With MP3-CD playback, have the freedom to personalize your sound settings to your tastes.

Enjoy digital quality DAB radio

- Tune into digital quality radio stations
- DAB and FM compatible for a complete radio experience

Unlimited listening pleasure

- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW
- Rip your favorite CDs to MP3

Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 60W RMS total output power

Start the day your way

- Digital tuning with 20 preset stations for extra convenience
- Wake up and sleep timer functions

PHILIPS

Highlights

DAB and FM compatible

DAB (Digital Audio Broadcasting) digital radio is, on top of FM analog transmission, a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear, crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can be find. With DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no returning on the move.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses

graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can

enjoy consistent sound even when you turn down the volume.

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

Rip your favorite CDs to MP3

Simply plug in your USB mass storage device to the USB port on Philips audio system and start recording your favorite music from CDs to your USB device or MP3 player - with one touch and no computer needed. So you can create your own MP3 files via direct MP3 digital recording.



Specifications

Sound

- Output Power: 2x60 watts music power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost
- Output power (RMS): 2 x 30W

Loudspeakers

- Main Speaker: Bass Reflex Speaker System, 2 way, 2" tweeter, 4" woofer

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Repeat/one/all/program, Shuffle Play, 20-Track Programmable
- ID3-tag support
- Loader Type: Front, Motorised
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

Audio Recording

- Recording Media: USB device
- USB recording modes: Instant record, Programmed tracks, Single disc, Single track
- USB recording sources: CD

Tuner/Reception/Transmission

- DAB: Band III, Info display, Menu, Smart Scan
- Tuner Bands: FM Stereo
- Auto digital tuning
- RDS: Station Name, Program Type, Radio Text, Station Information

- Station presets: 20
- Tuner Enhancements: Auto Store

Connectivity

- Aux in: Line in
- Headphone: 3.5 mm
- Other connections: Fixed FM & DAB T-shape antenna
- USB: USB host

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer, USB alarm
- Clock: On main display
- Eco Power Standby: 1 watt
- Display Type: Dot Matrix LCD
- Backlight color: Blue

Accessories

- Included accessories: Guarantee booklet, AC Power Cord, Quick Use Guide
- Remote control: 40-key with battery
- AC/DC Adaptor: Switching power supply

Dimensions

- Set dimensions (W x H x D): 211 x 250 x 160 mm
- Main speaker dimensions (W x H x D): 158 x 250 x 185 mm
- Packaging dimensions (W x H x D): 378 x 310 x 330 mm
- Weight incl. Packaging: 6.8 kg

Power

- Power supply: 100-240VAC, 50/60Hz



Issue date 2016-10-05

Version: 1.0.3

12 NC: 8670 000 37285
EAN: 87 12581 39767 8

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com