

Philips
DVD Micro Theater



MCD107

Movie cube

with USB direct playback

Enjoy the ultimate movie experience at home. The Philips DVD micro theater MCD107 plays DVDs, VCDs, CDs and more, and also features built-in USB Direct for photo and portable music playback. The compact design complements any home décor.

Enrich your movie experience

- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Dolby Digital for ultimate movie experience
- USB Direct for music and photo playback

Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2x5W RMS with 200W Peak Music Power Output

Design that blends into your interior(s)

- Stylishly sleek and compact design

PHILIPS

Specifications

Sound

- Output Power: 2x5W RMS / 400W PMPO
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost
- Sound System: Dolby Digital

Loudspeakers

- Main Speaker: 3.5" woofer, Bass Reflex Speaker System

Video Playback

- Playback Media: DVD+RW, DVD-Video, Picture CD, Video CD/SVCD
- Disc Playback Modes: Angle, Slow Motion, Zoom, A-B Repeat, PBC, Parental control
- DVD Region.: 3

Audio Playback

- Playback Media: MP3-CD, CD-RW, CD-R, CD, WMA-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Top
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Repeat, Shuffle

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Station presets: 20
- Tuner Enhancements: Auto Store

Connectivity

- Video Output - Analog: Composite CVBS (yellow cinch)
- Other connections: Line out, FM Antenna, Digital coaxial out
- Aux in: 3.5mm
- Headphone: 3.5 mm
- Audio Connections: 3.5mm Line in

Convenience

- Alarms: Sleep timer, CD Alarm, Radio Alarm
- Clock: On main display
- Display Type: LCD
- Backlight color: White

Accessories

- Included accessories: Composite video cable (Y), Guarantee booklet, Quick Use Guide, 3.5mm stereo line in cable
- Remote control: 40-key with Lithium batteries
- User Manual: English

Dimensions

- Set dimensions (W x H x D): 150 x 152 x 250 mm
- Main speaker dimensions (W x H x D): 150 x 152 x 197 mm
- Packaging dimensions (W x H x D): 530 x 310 x 206 mm
- Weight incl. Packaging: 5.48 kg

Power

- Power supply: 100-240VAC, 50/60Hz

Highlights

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dolby Digital

Because Dolby Digital, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2013-05-10

Version: 1.0.3

12 NC: 8670 000 50804
EAN: 87 12581 47232 0

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com