



Philips
docking speaker

for iPod/iPhone
Battery/AC powered



DS3000



Obsessed with sound

Fill your space with music and style

On your desk or anywhere else, this dashing docking speaker delivers crystal-clear sound that fills your personal space. Synchronize your iPhone/ iPod with your PC. Enjoy the option of AC or battery power for maximum flexibility.

Crystal clear sound

- DBB to preserve low tones for deep bass at any volume level
- Neodymium speakers for pure balanced sound
- Shielding technology to block mobile phone interference

Elegant and compact

- Compact design for any space, any lifestyle
- 360-degree design for gorgeous look from any angle

Advanced versatility

- PC synchronization with your iPod/iPhone
- Battery or AC power option for music enjoyment anywhere
- Dock any iPod/iPhone, even in its case
- AUX-in for easy connection to almost any electronic device
- Free DockStudio app for internet radio & other cool feature

docking speaker
for iPod/iPhone Battery/AC powered

Specifications

iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

iPod/iPhone/iPad App

- Compatibility: iOS 4.3 to iOS 10.3

iPod compatibility

- Compatible with: iPod, iPod classic, iPod mini, iPod nano, iPod nano 1st generation, iPod nano 2nd generation, iPod nano 3rd generation, iPod nano 4th generation, iPod nano 5th generation, iPod nano 6th generation, iPod touch, iPod touch 2nd generation, iPod touch 2nd gen 8/16/32GB, iPod with color display, iPod 5th generation

iPod/iPhone App

- App name: DockStudio
- Free download from App store
- Playback: album/track navigation, playback controls
- Sound settings: DBB, DSC-Flat, Pop, Rock, Jazz, Classic
- Clock: analog display, digital display
- Alarm: multiple alarms, sleep timer, wake up to music, wake up to nature sounds, wake up to photo
- 7000+ Internet radio stations
- Worldwide weather forecast

Sound

- Sound system: stereo

- Volume control: up/down
- Sound enhancement: Dynamic Bass Boost
- Output power: 8 W RMS

Connectivity

- PC Link: USB 2.0
- Aux in

Loudspeakers

- Speaker drivers: Neodymium magnet system

Power

- Power supply: battery, 100 - 240V AC, 50/60Hz
- Battery type: AA size (LR6)
- Number of batteries: 4
- Battery life time: 8 hr

Dimensions

- Gross weight: 1.33 kg
- Master carton weight: 3.03 kg
- Product dimensions (WxDxH): 210 x 150 x 135 mm
- Master carton dimensions: 300 x 240 x 145 mm
- Master carton quantity: 2
- Weight: 0.96 kg

Accessories

- Cables/Connection: MP3 Link cable, USB cable

Convenience

- Charging device: iPhone

DS3000/12

Highlights

Dynamic Bass Boost (DBB)



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Neodymium speakers

Neodymium is the best material for producing a strong magnetic field for greater sensitivity in a voice coil, better bass response and a pure balanced sound quality.

PC synchronization

Dock it, play it, sync it and charge it! Dig in to your favorite music on your iPod or iPhone while it charges and synchronizes with your PC via USB - and enjoy superb sound quality together with thoroughly unbeatable convenience. Let the great tunes go on and on - without ever running out of power.



Issue date 2017-12-30

Version: 9.0.8

12 NC: 8670 000 61557
EAN: 87 12581 53459 2

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com