



Philips AVENT  
Digital PhotoFrame

7"

Multimedia  
4:3 frame ratio

SPF2207



## Re-live the first smile

### Philips Avent PhotoFrame

This PhotoFrame is the perfect combination of quality and fun. Colorful frame accessories are also included for personalization - pink for girl and blue for boy. Instantly enjoy the most precious moments of your baby's first years.

#### **Top quality display for amazing viewing experience**

- imagen Pro for sharper and vibrant colors
- 4:3 aspect ratio for optimal distortion-free display
- Add new glow to old memories with RadiantColor

#### **Simple intuitive operation and great convenience**

- Automatic slideshow from USB or memory card
- Supports photos, videos and music
- Customize your frame with Pink or Blue snap-on frames.

#### **Environmentally friendly green design**

- Eco-friendly Photoframe
- Auto turning display on/off at preset times for power saving

**PHILIPS**  
**AVENT**

# Specifications

## Picture/Display

- Brightness: 200 cd/m<sup>2</sup>
- Viewing angle: @ C/R > 10, 120° (H) / 100° (V)
- Contrast ratio (typical): 300:1
- Lifetime, to 50% brightness: 20000 hr
- Aspect ratio: 4:3
- Panel resolution: 800 x 600

## Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

## Storage Media

- Built-in memory capacity: 512MB (for 500 HD photos)
- USB: USB flash drive
- Memory Card Types: Compact Flash type I, Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo (via adaptor), MS Pro Duo (via adaptor)

## Convenience

- Card Reader: Built-in (2x)
- Photo format supported: JPEG photo, Up to 10MB JPEG files, Up to 20 Megapixels
- Placement: Photo auto orientation, Landscape, Portrait
- Buttons and controls: 3 buttons, 4-way navigation key and enter
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Photo edit: Copy, Delete, Rotate, Zoom & crop
- Photo effects: Black and White, Frames, Sepia, Radiant color
- Slideshow setting: Random, Sequential, Transition effect
- Screen background: Black, White, Gray, Auto-fit
- Setup function: Brightness adjustment, Language, Status, Auto on/off, Beep on/off, Set time and date, Clock display enable/disable, Alarm
- System status: Firmware version, Remaining memory
- Connected media status: Connected media,

## Remaining memory

- Plug & Play Compatibility: Windows Vista, Windows 2000/XP or later, Mac OS X
- Regulatory approvals: BSMI, C-Tick, CCC, CE, FCC, GOST, PSB, Switzerland, UL/cUL
- On-Screen Display languages: English, Spanish, German, French, Italian, Dutch, Danish, Russian, Simplified Chinese, Japanese

## Accessories

- Included accessories: AC-DC Adapter, Stand, Quick start guide, User Manual

## Dimensions

- Set dimensions with stand (W x H x D): 206.4 x 139.3 x 103 mm
- Weight: 0.345 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -20°C to 70°C

## Power

- Power supply: 100-240VAC, 50/60Hz
- Power consumption: 5 W
- Power mode supported: AC powered

## Packaging dimensions

- EAN: 87 12581 47537 6
- Number of products included: 1
- Packaging type: Carton
- Packaging dimensions (W x H x D): 22.5 x 19 x 9 cm
- Gross weight: 1.05 kg
- Nett weight: 0.7 kg
- Tare weight: 0.35 kg

## Outer Carton

- GTIN: 1 87 12581 47537 3
- Number of consumer packagings: 2
- Gross weight: 2.3 kg
- Outer carton (L x W x H): 23.4 x 19 x 19.8 cm
- Nett weight: 1.4 kg
- Tare weight: 0.9 kg

# Highlights

## 4:3 perfect frame ratio

Philips digital PhotoFrame ensures your photo to be displayed in 4:3 ratio for the best viewing experience.

## Automatic slideshow

Automatic slideshows start from any USB drive or memory card for all those moments you don't want to spend time copying photos to your PhotoFrame.

## Customize with snap-on frames

Included are 2 beautifully designed and cheerful frame accessory. Pink for girls and blue for boys - sweet dreams guaranteed. Simply snap on.

## Eco-friendly Photoframe

Philips PhotoFrame are designed and produced according to our EcoDesign principles aimed at minimizing overall environmental impact, through lower power consumption, removal of hazardous substances, lower weight, more efficient packaging and better recyclability.

## imagen Pro

The unique Philips imagen enhancement technology automatically analyzes your photos to correct color and adjust for optimal contrast. imagen Pro is a more advanced image enhancement which includes the 3 essential elements from imagen to have more color accuracy, color depth and smart contrast. On top of these, imagen Pro offers enhanced skin color, sharper images and flicker-free photo viewing which is very important for still pictures.

## RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the color on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

## SmartPower

A timer turns PhotoFrame on and off at the hours you select, reducing energy consumption for the sake of our environment saving up to one third of your PhotoFrame energy costs.



Issue date 2021-01-12

Version: 2.2.4

12 NC: 8670 000 51299  
EAN: 87 12581 47537 6

© 2021 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)