



Philips
Universal remote control

4in1 France SAT

SRU5040



Full function replacement

Operates more than 1000 brands

A stylish chrome universal remote control that gives you complete control over most brands of TV, DVD player/recorder, VCR satellite receiver or cable set-top box. It has dedicated satellite keys and learns codes from your old remote.

Ideal replacement for your old remote

- 4-in-1 remote for your TV, DVD player/recorder, STB and VCR
- Convenient IR learning from another remote
- Ready for use with Philips equipment

Great convenience

- Dedicated Canalsat/TPS keys for easy Digital SAT box control
- Eye-catching chrome finish
- Drop it, splash it and just keep on using it!
- Battery low indication shows when to refresh batteries

Quick and easy set-up

- Automatically searches for your equipment brand
- Batteries are included for unwrap-and-zap
- For questions and assistance call our URC service line
- URC support service via dedicated website

PHILIPS

Specifications

Convenience

- Supported devices: TV, VCR, DVD, SAT, CABLE
- TV functions: Program up/down, Volume up/down, mute, Power/standby, Digit keys, AV selection, external, Menu control, Color/Brightness control, Teletext keys, Fast text keys, Previous program, Sleep/timer, 16:9, Guide, info
- Teletext enhancements: Fast text
- DVD functions: Transport keys, System menu control, Disc menu control, Digit keys
- VCR functions: Transport keys (6), Showview, VCR plus, Menu control
- SAT/CBL functions: Digit keys, Menu control, Guide, info, Favourites, Text functions, Unique SAT provider functions
- Ease of Installation: Autosearch
- Installation steps: 2
- Copy key function
- Language support: F
- Number of keys: 40
- Preprogrammed for Philips
- Regulatory approvals: CE Mark
- Splash proof

Accessories

- Battery: Yes, 1.5V Battery R03/AAA

Infrared Capabilities

- Operating distance: 33 ft (10 m)



- Transmitting LEDs: 1
- Universal IR code database
- Number of brands in database: Over 1100
- Carrier frequency range: 24 - 55 kHz
- Transmission angle: 90 degree
- Learning IR codes
- Learning frequency range: 20 kHz to 70 kHz and 455 kHz

Power

- Battery lifetime: 12 Months
- Battery type: AAA
- Number of batteries: 2

Outer Carton

- Quantity: 6
- EAN/UPC/GTIN: 87 10895 93603 3
- Height: 172 mm
- Length: 312 mm
- Width: 151 mm

Packaging Data

- 12NC: 908210006484
- EAN/UPC/GTIN: 87 10895 93602 6
- Height: 33 mm
- Length: 304 mm
- Width: 157 mm

Highlights

4-in-1 remote control

Replace a table full of remote controls with one robust unit that operates your TV, DVD player/recorder, satellite receiver, digital terrestrial receiver or cable set-top box (STB) and VCR, regardless of the brand or model.

Learning functionality

Learning functionality refers to the process through which a remote control captures and stores infrared signals from other remotes for later use. When device codes are not included in the on-board database, they can always be learned from the original remote, simply by pointing to it.

Pre-programmed for Philips

If you have Philips equipment, you can use your universal remote control without programming it because all keys are pre-set for Philips.

Dedicated Canalsat/TPS keys

Specially labelled function keys on the remote control make operating your Canalsat/TPS digital set-top box easier than ever before.

Chrome finish

Stylish chrome finish that looks good and complements the latest equipment design.

Splash and shock resistant

The tough housing can withstand splashes and spilled drinks, and is able to withstand a drop of at least one meter onto a hard floor.

Battery-low indication

To know in time when the batteries need to be recharged or replaced.

Auto brand search

Getting your new remote control working is simply a case of having your remote automatically search for the most suitable code for your equipment.

