



Philips
Digital Wireless
Headphone

- Over-ear
- Black

SHD9000



True CD sound quality with digital wireless

Kleer uncompressed audio

Headphones with Kleer uncompressed audio guarantees lossless transmission and 100% true to the original recording. With 100m range transmission and comfortable self-adjustable headband, it is a hassle free experience to enjoy music at home.

Superior listening experience

- Digital transmission ensures robust reception
- Kleer wireless technology
- 40mm high power neodymium speakers

Comfortable for long use

- Self-adjusting inner headband fits any head shape
- Ergonomic ear cushions design

Ease of use

- Docking station ensures care free recharging
- Non-interference with Wifi
- Extended 100m transmission range
- 2 x AAA rechargeable NiMH batteries for optimal weight

PHILIPS

Specifications

Product dimensions

- Product dimensions (W x H x D):
19 x 22 x 10,5 cm
- Weight: 0,29 kg

System

- Type: Radio Frequency (RF)

Sound

- Frequency response: 17 - 23 000 Hz
- Input level: 800mV (0dB) 2V (-8dB)

Tuner/Reception/Transmission

- Carrier frequency range: 2400 - 2483.5 MHz
- Effective range: Approx 100 meters (depending on ambient conditions)
- Modulation: MSK Digital
- Number of channels: 16
- Channel separation: 60 dB
- Distortion: 0.5% THD
- SN: 88dB Nominal

Convenience

- Operating time: up to 20 hours

Power

- Power requirement - headphones: Rechargeable NiMH batteries (supplied) or commercially available (size AAA) dry batteries
- Power requirements: DC 5V (from the supplied AC power adaptor)
- Radiated Output Power: 30 mW

Packaging dimensions

- EAN: 69 23410 71640 5
- Number of products included: 1
- Packaging type: Dummy
- Packaging dimensions (W x H x D):
24 x 28,5 x 11,5 cm
- Gross weight: 1,036 kg
- Nett weight: 0,648 kg
- Tare weight: 0,388 kg
- Type of shelf placement: Dummy

Outer Carton

- GTIN: 1 69 23410 71640 2
- Number of consumer packagings: 3
- Gross weight: 3,756 kg
- Outer carton (L x W x H): 37 x 26 x 32,5 cm
- Nett weight: 1,944 kg
- Tare weight: 1,812 kg

Highlights

40mm speaker drivers



40mm neodymium speaker drivers deliver superior HiFi sound performance.

2.4 GHz digital transmission

The 2.4 GHz digital transmission prevents compression and data loss between the transmitter and the headphones. The digital signals are converted to analog signals at the end of the transmission process. The end-result is superb sound quality, with smooth acoustics and minimal data loss.

Docking station



The docking station provides you a convenient station to place your receiver when not in use. It also takes care the battery charging.

Extended 100m transmission

The transmission range is now extended to 100m, you can enjoy a true hassle free music experience at home.

Kleer uncompressed audio

Kleer wireless technology deliver uncompressed audio ensures you can enjoy the true original music.

Self-adjustable inner headband



The inner headband makes it easy to obtain a perfect fit for your head. The mechanism adjusts automatically for comfort.



Issue date 2013-05-30

Version: 1.5.10

12 NC: 8670 000 92211
EAN: 69 23410 71640 5

© 2013 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com