

Philips ActionFit Sports earhook headphones

ActionFit

Earhook Purple



SHQ3200PP

Tuned for Sports

With adjustable earhook for secure fit

With its patented adjustable earhook, the lightweight & sweat-resistant SHQ3200 lets you focus on whatever workout you're doing, without losing motivation. If not for the amazing sound that keeps you going, you'll barely know they're there.

Designed for a secure and comfortable fit

- Patented adjustable ear hook for a secure fit
- 3 choices of ear cap sizes for optimal fit
- Ultrasoft silicon caps sit comfortably in your ears

Designed for high performance

- Sweat resistant and rain proof ideal for any workout
- · 8gm headphones for superb fit and ultra lightweight comfort
- Kevlar-reinforced cable for ultimate durability
- Reflective stopper in the cable
- · Cable clip and protective pouch for easy use and storage

Excellent sound with added bass boost

- Excellent sound generated by 9mm drivers
- · Powerful bass to boost motivation



SHQ3200PP/10

Specifications

Sound

- · Diaphragm: PET
- Frequency response: 15 22 000 Hz
- Impedance: 16 Ohm
- Sensitivity: 102 dB
- Type: Dynamic
- · Speaker diameter: 9 mm
- Maximum power input: 20 mW
- Voice coil: Copper
- Acoustic system: Closed
- Magnet type: Neodymium

Design

Color: Purple

Connectivity

- Connector: 3.5 mm
- · Cable length: 1.0 m
- · Cable Connection: two-parallel, symmetric
- · Finishing of connector: Gold plated
- · Type of cable: OFC

Accessories

• Storage pouch

Inner Carton

- Gross weight: 0,2007 kg
- GTIN: 2 87 12581 68804 6

- Inner carton (L x W x H): 18 x 8,2 x 10,5 cm
- Nett weight: 0,066 kg
- Number of consumer packagings: 3
- Tare weight: 0,1347 kg

Product dimensions

- Product dimensions (W \times H \times D): 5 \times 9 \times 2,8 cm
- Weight: 0,022 kg

Packaging dimensions

- Packaging dimensions (W \times H \times D): 9,5 \times 17,5 \times 2,5 cm
- EAN: 87 12581 68804 2
- Gross weight: 0,0559 kg
- Nett weight: 0,022 kg
- Number of products included: 1
- Packaging type: Dummy
- Tare weight: 0,0339 kg
- Type of shelf placement: Dummy

Outer Carton

- Gross weight: 1,8886 kg
- GTIN: 1 87 12581 68804 9
- Outer carton (L \times W \times H): 38 \times 18,1 \times 24,8 cm
- Nett weight: 0,528 kg
- Number of consumer packagings: 24
- Tare weight: 1,3606 kg

Highlights

Adjustable ear hook

With its patented adjustable ear hook, ActionFit headphones ensure the ultimate fit that's secure yet comfortable. Just hook the headphones on to your ears and slide the adjustable hook up or down to snugly fit your ear just so. Now you're all set to conquer any workout or terrain – your headphones are staying on, no matter what.

Clip and pouch

ActionFit headphones come with its own clip and pouch for easy cable management and safe storage. Enjoy a tangle-free workout with the clip, then stash your headphones in the breathable pouch. Don't sweat it!

Excellent sound

ActionFit headphones boast finely tuned 9mm drivers that are specifically designed to generate excellent sound. Sound so pristine and powerful that you'll easily immerse in your workout – and get the most out of your music and moves.

Kevlar-reinforced cable

Your ActionFit headphones are specially designed for durability and strength. Its Kevlar-coated cable is well protected against tearing and breaking, and can withstand extreme environments – and workouts.

Powerful bass

There's nothing better than a solid groove to get you into your workout rhythm. With ActionFit headphones, your grooves are powered by superbly deep and dynamic bass that will boost any routine, letting you take it to a higher level.

Reflective stopper

Reflective stopper in the cable

S, M, L, caps

3 choices of ear cap sizes for optimal fit

Soft silicon caps

Your ActionFit headphones come with ultrasoft silicon ear caps that are specially designed to sit snugly in your ears. They're so comfortable that you may never want to take them out.

Sweat and rain resistant

ActionFit headphones are specially designed for any active lifestyle. Whatever your sports or workout preference, your headphones can handle the heat, wet and sweat! Crafted with premium waterresistant materials, your headphones are comfortable sweat- and rain-proof.

Ultra light 8gm

Your ActionFit headphones weigh in at a mere 8gm, making them ultra lightweight and a pleasure to wear. In fact, you will hardly feel them when you're working out – just the superb, powerful sound that keeps you focused and motivated.



Issue date 2016-07-15

© 2016 Koninklijke Philips N.V. All Rights reserved.

Version: 2.0.6

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 03105 EAN: 87 12581 68804 2

www.philips.com