



Philips  
Wireless Headphone

SHC2000



## IR wireless

For TV

These full-size rechargeable infrared cordless headphones combine quality and convenience for either TV or music enjoyment in your home.

### **You'll forget you're wearing them!**

- Lightweight design improves comfort for prolonged use.
- Self-adjusting inner headband ensures a comfortable fit

### **The perfect wireless listening experience**

- High-frequency RF ensures clear and sharp reception
- ALC helps prevent audible distortion of input signals

### **Always ready to go**

- IR wireless transmission provides freedom of movement
- Reduces costs by using rechargeable batteries

**PHILIPS**  
sense and simplicity

## Specifications

### Sound

- Acoustic system: Closed
- Frequency response: 18 - 20,000 Hz
- Sensitivity: 108 dB
- Speaker diameter: 32 mm

### Tuner/Reception/Transmission

- Effective range: 7 m
- Channel separation: > 30 dB
- Carrier frequency range: 2.3 MHz (L) - 2.8 MHz (R)
- Modulation: FM

### Convenience

- Operating time: +/- 15 hours

### Electricity

- Power supply headphone: 2 x 1.5 V NiMH R03/AAA
- Power supply transmitter: AC/DC adapter 12 V/

200 mA

### Inner Box

- Gross weight: 4.505 kg
- Inner carton (L x W x H): 38.3 x 27.3 x 21.6 cm
- Net weight: 3.042 kg
- Tare weight: 1.463 kg

### Outer Box

- Gross weight: 11.28 kg
- Outer carton (L x W x H): 44.2 x 32.7 x 51.3 cm
- Net weight: 6.084 kg
- Tare weight: 5.196 kg

### Packaging dimensions

- Packaging dimensions (W x H x D): 20 x 22 x 9.5 cm
- Gross weight: 0.68 kg
- Net weight: 0.507 kg
- Tare weight: 0.173 kg

## Product highlights

### Lightweight design

The durable, lightweight quality materials enhance comfort for extended wearing.

### Self-adjusting inner headband

The inner headband makes it easy to obtain a perfect fit for your head. The mechanism adjusts automatically for comfort.

### High-frequency modulation

Using very high frequency modulation (RF) for the transmission link ensures sharp, clear reception.

### Automatic Level Control (ALC)

This smart electronic circuit ensures that the audio input level is automatically adjusted to the right level, preventing distortion and preserving your listening enjoyment.

### IR wireless transmission

IR wireless transmission allows you to be free from the hassles of cables.

### Rechargeable system

The headphone set incorporates facilities for recharging the batteries.



Issue date 2008-12-27

Version: 4.0.5

12 NC: 9082 100 07982  
EAN: 87 10895 95963 6

© 2008 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)