

Philips
DVD player

DivX

DVP5100



See, hear, play everything

Be impressed with this Philips DVD player. Step into another home entertainment arena as you immerse yourself with DivX® movies and Windows Media™ Audio in your own living room.

Great audio and video performance

- RGB on Scart single connection for high-quality video
- 12-bit/108MHz video processing for sharp, natural images
- 192kHz/24 bit audio DAC enhances analogue sound input
- Progressive Scan component video for optimized image quality

Plays it all

- Movies: DVD, DVD+R/RW, DVD-R/RW, (S)VCD, DivX
- Picture CD (JPEG) with music (MP3) playback
- Music: CD, MP3-CD, CD-R/RW & Windows Media™ Audio

Fits everywhere, goes anywhere

- Ultra-slim design



PHILIPS

sense and simplicity

Specifications

Picture/Display

- **Aspect ratio:** 4:3, 16:9
- **D/A converter:** 12 bit, 108 MHz
- **Picture enhancement:** Progressive Scan, Smart Picture Setting

Sound

- **D/A converter:** 192kHz/24-bit
- **Signal to noise ratio:** 95 dB
- **Distortion and Noise (1kHz):** 80 dB
- **Crosstalk (1kHz):** 90 dB
- **Dynamic Range (1kHz):** 85 dB
- **Sound System:** Dolby Digital
- **Sound Enhancement:** 3D Virtual Surround, Night Mode, Smart sound

Video Playback

- **Playback Media:** CD, CD-R, CD-R/CD-RW, Video CD/SCD, DVD+RW, DVD+R, DVD-R, DVD-RW (Video mode), DVD-Video
- **Compression formats:** MPEG1, MPEG2, MPEG4, DivX 3.11, DivX 4.x, DivX 5.x, XviD
- **Video disc playback system:** NTSC, PAL

Audio Playback

- **Playback Media:** CD, CD-R, CD-RW, MP3-CD
- **Compression format:** PCM, MP3, Windows Media™ Audio
- **MP3 bit rates:** 32 - 256 kbps

Still Picture Playback

- **Playback Media:** Picture CD, DVD+R/+RW

- **Picture compression format:** JPEG
- **Picture enhancement:** Flip photos, Rotate, Zoom, Slideshow with MP3 playback

Connectivity

- **Other connections:** Scart, ComponentVideo out, Progressive, Composite video (CVBS) out, Analogue audio Left/Right out, Digital coaxial out

Convenience

- **Child Protection:** Parental Control, Child Lock
- **On-Screen Display languages:** Dutch, English, French, German

Power

- **Power supply:** 50Hz, 220-240V
- **Power consumption:** 10 W
- **Standby power consumption:** < 0.8 W

Accessories

- **Batteries:** 2 x AA
- **Cables:** None
- **Remote control:** 3141 017 90221
- **User Manual:** English
- **Warranty Card**

Dimensions

- **Set dimensions (W x H x D):** 435 x 37 x 265 mm
- **Set weight:** 2.03 kg
- **Packaging dimensions (W x H x D):** 490 x 82 x 352 mm
- **Weight incl. Packaging:** 3.32 kg

Product highlights

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

RGB on Scart connectivity

RGB on Scart is a cable connection that provides easy connectivity for high quality video output.

12-bit/108MHz video DAC

12-bit Video DAC is a superior Digital-to-Analogue-Converter that preserves every detail of the authentic picture quality. It shows subtle shades and smoother graduation of colours, resulting in a more vibrant and natural picture. The limitation of the usual 10bit DAC become in particular apparent while using large screens and projectors.

192kHz/24 bit audio DAC

192KHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

Multi-format Movies with DivX

Multi-format playability allows you to play most disc formats for maximum disc compatibility and viewing pleasure.

Music: Windows Media™ Audio

Multi-format playability allows you to play most disc formats for maximum disc compatibility and listening pleasure.

Picture CD with MP3 Playback

Picture CD is a CD-R or CD-RW disc on which you can store your MP3 and digital pictures. When inserting a Picture CD in the DVD player, a screen menu will pop up, showing your JPEGs and/or MP3 files on the disc. Just select the music and pictures files you wish to enjoy and press play or OK. You can watch your pictures on TV with your music playing simultaneously.

Ultra-slim design

The attractive enclosure has a very low profile.

