

Music, photos and movies here, PC there

Wirelessly from your PC to TV



Step away from the PC. Start enjoying your digital music, photos and videos as they were supposed to be enjoyed.

Watch downloaded movies

- Watch downloaded movies in comfort on your TV
- Supports WMV and Xvid video formats

Enjoy PC music anywhere in your house

- Stream high-quality music from your PC to the audio system
- Listen to Internet Radio without your PC.
- Play secure WMA (DRM) songs from online music services
- Supports WMA, WMA-DRM and MP3 music formats

Share your digital photos

- Watch your HD photo slideshow on your TV with your friends
- Keep your photos stored on the PC while viewing on the TV
- Crisp and sharp high definition photo quality on your LCD TV

Smart and simple

- Friendly step-by-step installation gets you started quickly.
- Less clutter. Less fuss. Wireless link means no drilling.



impression
only

PHILIPS

Technical specifications

Video playback

- **Compression formats:** Divx 3.11, Divx 4, Divx 5, MPEG1, MPEG2, MPEG4, XviD, WMV, WMV-DRM

Audio Playback

- **Compression format:** MP3, PCM, WAV, WMA-DRM, WMA
- ID3 tag support

Still picture playback

- **Picture compression format:** JPEG
- **Picture enhancement:** Slideshow with MP3 playback, Rotate, High Definition Resolution

Connectivity

- **Encryption / security:** WEP 128bit, WEP 64bit, WPA
- **LAN wired:** Ethernet (RJ 45) 1x
- **Video output - analogue:** Audio L+R (on SCART), Component RGB (SCART), Composite CVBS (on SCART), Component Y Pb Pr (cinch)
- **Wireless connections:** Wireless LAN(802.11b/g)
- **Audio output - digital:** Coaxial (cinch)

Accessories

- **AC/DC adaptor:** 12V DC, 2.5A
- **CD-ROM:** Philips Media Manager & manual
- **Included accessories:** AC power cord, Batteries for remote control, Scart cable
- Remote control
- User manual
- Quick start guide

Software

- **Philips Media Manager:** UPnP multimedia content server

System Requirements

- CD-ROM drive
- **Hard disc space:** 100 MB
- **Mac OS:** 10
- **PC OS:** Windows® 98 SE, 2000, ME, XP
- **Processor:** Pentium II or better
- **RAM memory:** 64 MB
- **PC network required:** Wireless or wired PC network
- **Internet connection:** Broadband Internet (>256 kbps)
- **My.philips.com:** Internet access and email

Dimensions

- **Product dimensions (WxDxH):** 207 x 152 x 40 mm
- **Product weight:** 0.84 kg

Power

- **Mains power:** AC 100-240V 50-60Hz
- On/Off switch
- **Power consumption:** 15 / 2 (standby) W
- **Power LED indicator:** Operation, blue, Red

Internet services

- **Audio services:** Live 365.com, Andante, Radio Free Virgin, Playhouse radio, ...and more
- **Video services:** Yahoo! Movies, Launch, iFILM
- **Photo services:** Yahoo! Photos
- **My streams:** Add your own Internet streams

Product highlights

Internet music

Add more radio stations to your current audio system by connecting directly via your broadband Internet connection to the Internet Radio Station.

Wireless PC Music Link

Stream music from your PC to your audio system in high quality. Listen on your audio system to music files stored on the PC. Select songs from your music collection according to artist, album or genre.

Photos on TV

Sit on your couch and watch your holiday photos with the whole family or your friends.

Central photo storage

Keep your photo collections centrally stored on your PC and enjoy them wirelessly on your TV.

WMV and Xvid support

Store your video collection and downloaded movies on your PC in one of the many supported video formats. Then playback on your TV. Playback of MPEG1, 2 and 4, WMV and Xvid video formats is supported.

Watch downloaded movies

Download and store your movies on your PC and view them from the comfort of your couch in the living room. No hassle burning downloaded movies on to CD or DVD, but direct access and control at your fingertips.

Automatically updates

The product is capable of adding new and improved functionality by upgrading the software. It will check via a broadband internet connection for the availability of new software versions. You can easily decide if you want to upgrade and enjoy even more features.

Step-by-step installation

The product is easily installed by the user friendly step-by-step approach. On the TV screen, you can see all the steps needed to install the product.

Goodbye cables

A 2.4 GHz wireless link between the receiver and transmitter means you don't have to lay cables or drill holes through walls.

Play secure WMA (DRM) songs

WMA-DRM and MP3 support

Store your music collection and downloaded songs on your PC in one of the many supported audio formats. Then playback on your audio system. Playback of WMA, WMA-DRM and MP3 music formats is supported

Works with multiple PC's

You can access multimedia content from various PC's in your house. The media manager works on many PC's; even older PC's. So from one Media Adapter you can access the multimedia content on a different PC. No need to copy your files to another PC.

High Definition Photo

Use the high definition TV output on your LCD TV to display your digital photos crisp and sharp



Date of issue 2005-07-13

Version: 1.0

12 NC: 9082 100 04284
EAN: 87 10895 87926 2

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
© 2005 Koninklijke Philips Electronics N.V.
All Rights reserved.
www.philips.com