



Philips
Webcam

VGA
CMOS

SPC715NC



Boost your video-chat experience

With face-tracking and digital zoom

Take your video-chatting to the next level. This high resolution webcam with face-tracking and 5x digital zoom will make you feel like you're on TV. Its built-in digital microphone is complemented by a headset for echo-free chatting.

Superb video chatting experience

- Multimedia headset and head mic for best sound quality
- Add top-quality video and speech to calls
- Face tracking automatically follows your face
- Rotating lens for perfect aiming and natural images
- Built-in digital microphone for quality sound

Enhanced image quality

- Smooth image with 30 frames per second video
- Super VGA resolution for high-quality images
- Precision glass lens offers sharper image quality

Perfectly user-friendly

- 5x digital zoom for superb close-ups
- Create V-mails and control your webcam with VLounge Premium
- VLounge QuickLaunch button for instant operation
- Compatible with MSN, Skype and other free messaging services

PHILIPS
sense and simplicity

Highlights

Multimedia headset included

Included with your webcam is a Philips multimedia headset. The head mic ensures optimum sound quality and comfortable use.

Add top-quality video

The webcam has been designed to add video to your internet calls so you can see as well as hear your friends and family online. It works easily and instantly and is entirely future-proof!

Automatic face tracking

The state-of-the-art camera software automatically detects your face and moves the lens to follow you as you move. You stay in the center of the image even if you move during a video conference. It gives you the freedom to express yourself and converse naturally.

Rotating lens

Rotating lens for perfect aiming and natural images. You can get the right camera angle quickly and easily without having to put things underneath it to change the tilt.

Built-in digital microphone

The built-in digital microphone allows you to talk naturally and freely or to add sound to a video clip recording.

30 frames per second video

Sit back and enjoy superior viewing with 30 frames per second video. This gives you smoother video images and a better all-round video-chatting experience.

Super VGA resolution

The webcam captures Video Graphics Array (VGA) quality (640x480) snapshots and flicker-free video

clips for video mails. With VGA resolution, your webcam becomes a professional level camera. Add high quality photos to documents, webpages and e-mails in an instant, or print out photo-quality images.

Precision glass lens

Sharp, crisp and clear. Precision glass lens guarantees you high image quality for all applications - from snapshot to video messaging. The finished lenses are coated with a special film to extend their working life and protect them from wear and tear and dust accumulation.

5x digital zoom

Zoom in and out to get the perfect framing for any image. You control the zoom entirely via the onscreen interface while you're looking at the image so you can adjust it perfectly.

VLounge Premium

Create and send V-mails in seconds. VLounge is sophisticated software for capturing, managing and archiving snapshots and video clips with just a couple of mouse clicks. You can also use it to operate face tracking and digital zoom for maximum control.

VLounge QuickLaunch button

To start up the VLounge application, simply press the QuickLaunch button

Compatible with MSN and Skype

The webcam and its software have been designed with all messaging systems in mind. Add video to Skype, MSN Messenger, Yahoo!, AOL Messenger and other free messaging services. It also works with Windows Messenger and NetMeeting for multi-person video-conferencing and is designed to be future-proof.

Specifications

Video & snapshot capturing

- Sensor: CMOS
- Sensor resolution: VGA
- Video resolution: VGA
- Snapshot resolution: VGA
- Interpolated snapshot res.: SVGA
- Max. frame rate: 30 fps
- Lens: F2.8, D50°
- White balance: 2600 – 7600 k
- Min. illuminance: < 5 lux
- Color depth: 24 bit

Mechanics

- Laptop clamp
- LCD clamp
- CRT stand
- Desktop stand
- Digital built-in microphone
- Quicklaunch button
- Snapshot button

Accessories

- Included accessories: Quick install guide, User Manual, Multimedia headset

Software

- VLounge: Premium
- Add video to: MSN Messenger, Yahoo! Messenger, AOL Messenger, Skype

System Requirements

- Operating System: Microsoft Windows 98, Microsoft Windows ME, Microsoft Windows 2000, Microsoft Windows XP
- Processor: Pentium II 500MHz or faster
- RAM memory: 128 MB RAM
- Sound card
- USB: Free USB port
- Internet connection
- Hard disk space: 200 MB
- CD-ROM or DVD-ROM Drive

Connectivity

- Cable length: 2.1 m
- PC Link: USB 1.1

Dimensions

- Product dimensions (W x H x D):
74 x 142 x 74 mm
- Product weight (g): 110

Packaging Data

- 12NC: 908210008638
- EAN/UPC/GTIN: 87 10895 97715 9
- Gross weight: 0.614 kg
- Height: 230 mm
- Length: 230 mm
- Width: 90 mm
- Quantity: 1
- Tare weight: 0.514 kg

Outer Carton

- EAN/UPC/GTIN: 87 10895 97991 7
- Quantity: 6
- Gross weight: 4.384 kg
- Tare weight: 3.724 kg
- Length: 475 mm
- Width: 285 mm
- Height: 248 mm



Issue date 2013-01-22

Version: 2.0.5

12 NC: 9082 100 08638
EAN: 87 10895 97715 9

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com