

Philips
Compact home theatre
system

CTS4000



Seduced by design, surrounded by sound

with the all-in-one home cinema

Enjoy the magic of movies in tighter spaces with this compact cinema system. Featuring an integrated universal iPod dock, a built-in subwoofer and Cinema Sound it immerses you in sound and quality video with HDMI 1080p upscaling.

Hear and see

- Cinema Sound for a wider, immersive sound experience
- Built-in subwoofer for incredible bass without the wires
- FullSound™ to bring your MP3 music to life
- HDMI 1080p upscales to high definition for sharper pictures

Live and connect

- Plays multiple disc and media formats
- Built-in dock for convenient playback from your iPod/iPhone
- USB and MP3 Link to connect all portable devices
- Compact design that fits anywhere, entertains every time

Use

- Stunning single unit for great sound without the clutter

PHILIPS

Highlights

Cinema Sound

Cinema Sound delivers dynamic sound from a single unit system, and an unbeatable listening experience in any sort of space. Using a carefully calculated mix of array processing, psychoacoustics and precise driver positioning, Cinema Sound delivers a sound field that is significantly widened, providing the listener with immersive sound – absolutely clutter-free.

Built-in subwoofer

A built-in subwoofer provides all the low tones that are essential to a great listening experience - whether you are watching a movie or playing a music CD. The deepest bass notes come out rich and clear, ensuring sensational entertainment with the intensity and vim that was meant to be. Despite delivering a sound experience at full tilt, the built-in subwoofer carries with it none of the clutter - allowing you to savour complete entertainment while keeping your room completely fuss-free. Now enjoy both your room and the boom.

FullSound™

Philips' innovative FullSound technology faithfully restores sonic details to compressed MP3 music, dramatically enriching and enhancing it, so you can experience CD music without any distortion. Based on an audio post-processing algorithm, FullSound combines Philips' renowned expertise in music reproduction with the power of the latest generation Digital Signal Processor (DSP). The result is fuller bass with more depth and impact, boosted voice and instrument clarity, and rich detail. Rediscover your compressed MP3 music in true-to-life sound that will touch your soul and move your feet.

HDMI 1080p



HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can

now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multi-channel audio, without conversions to analogue - delivering perfect picture and sound quality, completely free from noise.

Built-in dock for iPod/iPhone

A built-in dock for iPod/iPhone lets you play movies, music and photos from your iPod/iPhone. What's more, you can charge and control the iPod/iPhone and browse through its contents on your TV screen - all with the home theatre's remote. Doing away with cumbersome cables and connections, the integrated dock brings portable entertainment into your home - with absolute ease.



Specifications

Picture/Display

- Picture enhancement: High Def (720p, 1080i, 1080p), Video Upscaling (720p, 1080i/p)

Sound

- Total Power (RMS): 50 W
- Frequency response: 180 Hz ~ 18 kHz/±3 dB Hz
- Signal to noise ratio: > 60 dB (A-weighted)
- Sound Enhancement: Night Mode
- Sound System: Dolby Digital, DTS, MPEG2, Stereo, Cinema Sound
- Equalizer settings: Action, Classic, Concert, Gaming, News, Party, Rock

Connectivity

- Front/Side connections: Dock connector, Headphone output 3.5 mm jack, Hi-Speed USB
- Rear Connections: 12 V DC in, AUX in, Composite video (CVBS) output, HDMI output, MP3 Link

Video Playback

- Compression formats: DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, MPEG1, MPEG2, MPEG4, WMV
- Playback Media: CD-R/CD-RW, DVD+R/+RW, DVD-R/-RW, DVD-Video, Video CD/SVCD
- Video disc playback system: NTSC, PAL

Audio Playback

- Compression format: Dolby Digital, DTS, MP3,

- MPEG2 Multi-channel, PCM, WMA
- Playback Media: Audio CD, CD-R/RW, DVD+R/+RW, DVD-R/-RW, USB flash drive

Still Picture Playback

- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate, Slideshow with music playback, Zoom
- Playback Media: CD-R/RW, DVD+R/+RW, DVD-R/-RW, USB flash drive

Power

- Power consumption: 22 W
- Standby power consumption: < 1 W
- Power supply: AC/DC Adapter, 100-240 VAC, 50/60 Hz

Accessories

- Included accessories: 2 x AAA Batteries, AC-DC Adapter, CVBS video cable, HDMI cable, Quick start guide, RCA to SCART cable, Remote Control, World Wide Warranty leaflet, MP3 Line-in cable, User Manual

Dimensions

- Product weight: 2.6 kg
- Product dimensions (W x H x D): 273 x 172 x 273 mm
- Packaging dimensions (W x H x D): 385 x 254 x 330 mm



Issue date 2017-04-04

Version: 8.1.9

12 NC: 8670 000 38731
EAN: 87 12581 41038 4

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com