

Philips
DVD player

DVPI 120



Simply plays it all

Does size matter? Ever heard of less is more? Introducing the best value DVD player. No complications! Just a simple set that plays practically any disc format, including your digital photos, with absolutely no compromise to picture quality.

Brings audio and video to life

- 12-bit/108 MHz video processing for sharp, natural images
- 192 kHz/24-bit audio DAC enhances analogue sound input
- High-quality outputs for analogue and digital audio
- Progressive Scan component video for optimised image quality

Plays all your movies and music

- Plays CD, (S) VCD, DVD, DVD+R/RW, DVD-R/RW
- Plays MP3, WMA and JPEG digital camera photos

Fits any space, any lifestyle

- Ultra-slim design that fits anywhere

PHILIPS
sense and simplicity

Specifications

Picture/Display

- **D/A converter:** 12-bit, 108 MHz
- **Picture enhancement:** Progressive Scan, Video upsampling

Sound

- **D/A converter:** 24-bit, 192 kHz
- **Frequency response:** 30-20,000 Hz
- **Signal to noise ratio:** 90
- **Distortion and Noise (1 kHz):** 65 dB
- **Crosstalk (1 kHz):** 70 dB
- **Dynamic Range (1 kHz):** 80 dB
- **Sound System:** Dolby Digital

Video Playback

- **Playback Media:** CD, CD-R/CD-RW, Video CD/SVCD, DVD, DVD+R/+RW, DVD-R/-RW, DVD-Video
- **Compression formats:** MPEG1, MPEG2
- **Video disc playback system:** PAL, NTSC

Audio Playback

- **Playback Media:** CD, MP3-CD, MP3-DVD, WMA-CD, CD-R/RW, Audio CD
- **MP3 bit rates:** 32 - 320 kbps
- **Compression format:** MP3, Dolby Digital, PCM, WMA

Still Picture Playback

- **Playback Media:** DVD+R/+RW, DVD-R/-RW, CD-R/RW, Picture CD, Kodak Picture CD

- **Picture compression format:** JPEG
- **Picture enhancement:** Flip photos, Rotate, Zoom, Slideshow

Connectivity

- **Rear Connections:** Analogue audio Left/Right out, Component/Video out Progressive, Digital coaxial out, CVBS & analogue audio L/R output

Convenience

- **Child Protection:** Child Lock, Parental Control
- **On-Screen Display languages:** English, Canadian French, Mexican Spanish

Electricity

- **Power consumption:** < 10 W
- **Standby power consumption:** < 0.8 W
- **Power supply:** 120 V, 60 Hz

Accessories

- **Included Accessories:** 2 x AAA Batteries, Remote Control, User Manual, Audio/Video cable, Product Registration Card, Warranty Leaflet

Dimensions

- **Packaging dimensions (W x H x D):** 300 x 335 x 92 mm
- **Set dimensions (W x H x D):** 252 x 52 x 250 mm

Multimedia Applications

- **Playback Formats:** JPEG Still pictures, MP3

Product highlights

192 kHz/24-bit audio DAC

192 kHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, it writes both fields at the same time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

Plays it all

Play MP3s, WMA and JPEGs, and experience the convenience of sharing media files on your TV or home theatre system - in the comfort of your living room.



Issue date 2009-02-16

Version: 1.0.7

12 NC: 8670 000 33189
UPC: 6 09585 14137 7

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com