

Philips
Micro Hi-Fi System

MCM704D



Enjoy your tunes in Hi-Fi sound quality

Play and charge your iPod

With a mirror-finished center-unit that adds a touch of stylishness to any interior. The wood-finished speakers deliver high quality sound and with USB Direct playback, you can now satisfy your audio needs on one micro system.

Play your iPod content out loud at home

- Play and charge your iPod
- Single remote control for the system and iPod

Enrich your sound experience

- Enjoy MP3/WMA music directly from your portable USB devices
- Play MP3/WMA-CD, CD and CD-RW
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Loudness for bass and treble enhancement
- 2x25W RMS/50W Total Power

Design that blends into your interior(s)

- High-end component design with stand
- Elegant wood-finished speakers

PHILIPS
sense and simplicity

Highlights

USB Direct for MP3/WMA music



Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges

for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Loudness for bass and treble

In the sound spectrum, high and low frequencies are relatively less audible to human ears - especially at low volumes. By activating the Loudness feature, the bass and treble will be amplified so you can savor a more balanced sound perception overall.

High-end component design



The component-designed DVD micro system comes with a stand that features four triangular feet. It can prevent any audio frequency distortion due to vibration, overheating and electromagnetic interference generated from the amplifier and DVD loader. The result is smooth and excellent and sound reproduction.



Specifications

Sound

- Output Power: 2x25W RMS, 50W Total Power
- Sound Enhancement: Loudness, Digital Sound Control 4 modes, Dynamic Bass Boost

Loudspeakers

- Main Speaker: 4" woofer, Speaker grilles detachable, Bass Reflex Speaker System

Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD-RW, CD-R, CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Motorised, Top
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop
- Cradle playback mode: Charging iPod, Fast forward and backward, Next and Previous track, Play and Pause

Tuner/Reception/Transmission

- Auto digital tuning
- Station presets: 40
- Tuner Bands: FM Stereo, AM
- Tuner Enhancements: Auto Store

Connectivity

- Other connections: FM Antenna, Cradle connection, AM Antenna
- Aux in: 1x(L/R)/ RCA
- Headphone: 3.5 mm
- USB: USB host

Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm, USB alarm
- Clock: On main display
- Display Type: VFD display
- Eco Power Standby: 1 watt
- Indications: DIM mode

Accessories

- Included Accessories: AM/FM Antenna
- Remote control: 24-key with Lithium batteries
- Quick start guide: English, French, Spanish
- User Manual: English, French, Spanish
- Cables: Docking cable
- Cradle: Cradle and adaptors for iPod
- Warranty Card: USA Warranty Card

Dimensions

- Set dimensions (W x H x D): 208 x 156 x 268 mm
- Main speaker dimensions (W x H x D): 150 x 150 x 225 mm
- Packaging dimensions (W x H x D): 496 x 375 x 244 mm
- Weight incl. Packaging: 9 kg

Power

- Power supply: 120V, 60Hz

iPod compatibility

- Compatible with: iPod, iPod mini, iPod nano, iPod with color display, iPod 5th Generation



Issue date 2009-11-06

Version: 2.0.5

12 NC: 8670 000 32743
UPC: 6 09585 14010 3

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com