

Philips
Home Theatre Control
Panel



SBCRU1000



Total overview of everything you want to control

The perfect solution to keep you up to date and in control of your home and all your entertainment devices, fully customisable to the needs of you and your family.

The total control solution

- Extensive infrared code database for any device or brand
- Convenient infra red learning from another remote by pointing to it
- A single point for control for home automation systems
- Integrated WiFi connectivity for wireless networking

Fully customisable user interface

- Attractive and easy-to-read touch screen colour LCD display
- Alpha blending allows see-through buttons and backgrounds
- Large memory capacity stores all your settings
- PC software to create your own user interface

Great convenience

- Auto-update of personalized TV listings from the internet
- Multiple commands combined into one-touch control
- Settings and codes are retained when replacing the batteries
- Pick-up sensor activates the remote control when picked up

PHILIPS

Technical specifications

Picture / Display

- Backlight
- **Diagonal screen size (inch):** 6.4 inch
- **Display colours:** 65,536
- **Resolution:** 640 x 480 pixels
- Touch panel

Infrared Capabilities

- **Operating distance:** 33 ft (10 m)
- Learning IR codes
- **Learning frequency range:** Up to 78 kHz and 455 kHz
- **Transmitting LEDs:** 5
- Universal infra red code database
- **Number of brands in database:** Over 1300

Connectivity

- **Encryption / security:** WEP 128bit
- **Microphone:** Built in microphone
- **Network mode:** DHCP, Fixed IP
- **USB:** USB 1.1
- **Wireless LAN:** 802.11b

Customisation

- **Editor application on PC:** iProntoEdit
- **On screen customisation:** No
- Full screen configurability
- Transparency
- Alpha-blending
- **Macros:** Up to 250 steps

Convenience

- Automatic power off
- **Cradle / docking station:** no
- **Electronic Programme Guide:** TV guide on screen
- Hard buttons
- **Multi language:** No

- Pick up sensor
- **Programmable timers:** No
- Scroll wheel

Multimedia Applications

- **Memory card types:** Multi-Media Card (MMC)

Power

- **Charging time:** approximately 1 hour hr
- **Mains power:** AC 100-240 V 50-60 Hz 1500 mA

Dimensions

- **Master carton quantity:** 2
- **Product dimensions (W x H x D):** 240 x 178 x 23 mm
- **Product weight:** 0.9 kg
- **Temperature range (operation):** 5°C to 45°C

System Specifications

- **CPU:** Intel Xscale 32 bit
- **CPU speed:** 400 MHz
- **Flash memory size:** 64 MB
- **Ram size:** 64 MB

System Requirements

- CD-ROM drive
- **Hard disc space:** 75 MB
- **PC OS:** Windows 98 SE, 2000, ME, XP
- **RAM memory:** 64 MB

Accessories

- **AC/DC adaptor:** 12 V 4.16 A (50W max)
- **Batteries:** Li-ion 2700 mAh
- **Charger:** International (110 - 240 V AC)
- **Docking Station:** no
- Quick start guide
- User Guide on CD-ROM
- Warranty card

Product highlights

Universal infra red code database

A universal IR code database refers to a library of infrared codes built-in to a particular remote. This feature allows a remote to control your equipment without needing to learn individual signals. Select the correct infrared code sets in the database for the devices you want to control, to enable control of virtually every audio/video system element on the market today – regardless of model or brand.

Learning functionality

Learning functionality refers to the process through which a remote control captures and stores infrared signals from other remotes for later use. When device codes are not included in the on-board database, they can always be learned from the original remote, simply by pointing to it.

Home automation control

Control of not only audio and video devices but also other devices in the home such as lighting, climate, curtains, etc.

Integrated WiFi

WiFi networking, also known as IEEE 802.11 uses radio frequency signals to communicate in a similar fashion as wired computer networks. It uses TCP/IP networking protocols for the basic communication.

Colour touchscreen LCD display

Colour Liquid Crystal Display with touch screen input ensures better readability and the capability to visualise colour buttons and backgrounds. Easy selection of buttons and commands is possible using the touch screen.

Alpha blending

Alpha blending is used to create the effect of transparency. It does this by combining a translucent foreground with a background colour to create an in-between blend.

Large memory capacity

The amount of space included on a remote control for storing all settings. It allows nearly unlimited macro functionalities, number of devices and layouts.

PC software included

Electronic program guide

The electronic program guide (EPG) lists current and scheduled programs that are or will be available on each channel and gives a short summary or commentary for each program. It's automatically updated if the schedules change, and you can choose the type or genre of programs you like to view, so you won't miss anything.

Internet access

A feature that allows a product to be connected to the internet to enhance its functionality. The product can connect to the internet making use of an existing broadband internet account. Through a WiFi wireless or wired home network it connects via a router to the broadband modem.



Date of issue 2006-10-06

Version: 5.0

12 NC: 9082 100 02333
EAN: 87 10895 79181 6

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.
© 2006 Koninklijke Philips Electronics N.V.
All Rights reserved.
www.philips.com

