

Philips
Earhook Headphones

SHJ035



Innovation for athletes

3-way adjustable sport headphones

Stereo sound just got sleeker. A radical new design aimed at athletes and audiophiles, Vapor Flight sport headphones are small, lightweight and three-way adjustable for a world of different size ears.

Innovation for Athletes

- A 1.2m long cable that is ideal for outdoor use
- 15mm speaker driver optimizes wearing comfort
- 3-way adjustment for personalized comfort and stability
- Copper Cladded Aluminium Wire improves sound quality
- Lightweight design improves comfort for prolonged use.
- Neodymium magnet enhances bass performance and sensitivity
- for excellent comfort and durability
- Reinforced cable connection ensures extra durability
- for use in active sports

PHILIPS
sense and simplicity

Specifications

Sound

- Acoustic system: Open
- Magnet type: Neodymium
- Voice coil: CCAW
- Diaphragm: Mylar dome
- Frequency response: 10 - 22 000 Hz
- Impedance: 16 Ohm
- Maximum power input: 50 mW
- Sensitivity: 102 dB
- Speaker diameter: 15 mm
- Type: Dynamic

Connectivity

- Cable Connection: Two-parallel, symmetric
- Cable length: 1.2 m
- Connector: 3.5 mm stereo
- Finishing of connector: Chrome plated
- Type of cable: OFC

Outer Carton

- 12NC: 867000027424
- EAN/UPC/GTIN: 1 06 09585 12667 8
- Gross weight: 0.400 kg
- Height: 197 mm
- Length: 191 mm
- Net Weight: 0.200 kg
- Quantity: 3
- Tare weight: 0.200 kg
- Width: 171 mm

Packaging Data

- 12NC: 867000027424
- EAN/UPC/GTIN: 6 09585 12667 1
- Gross weight: 0.076 kg
- Height: 174 mm
- Length: 176 mm
- Net weight: 0.026 kg
- Tare weight: 0.050 kg
- Width: 52 mm

Highlights

1.2 meter cable

The ideal cable length to give you the freedom to put your audio device where you want.

15 mm speaker driver

Small enough for optimum wearing comfort and big enough to deliver crisp, non-distorted sound, the 15 mm speaker driver is an ideal size for listening enjoyment.

3-way adjustable

Enjoy a snug, personalized fit and optimum stability, even when you're active or on the move. With three-way adjustment, your comfort is guaranteed.

CCA W voice coil

By using top-quality Copper Cladded Aluminium Wire (CCA W) in the headphone driver's voice coil, the sound quality is considerably improved.

Lightweight design

The durable, lightweight quality materials enhance comfort for extended wearing.

Neodymium magnet

Neodymium is the best material for producing a strong magnetic field for greater sensitivity in a voice coil, better bass response and higher overall sound quality.

Plastic housing

for excellent comfort and durability

Reinforced cable connection

A soft plastic part on the earshell reduces cable strain, protects the connection and prevents damage from repeated bending.

Sweat-resistant ear cushions

for use in active sports



Issue date 2009-05-27

Version: 2.1.8

12 NC: 8670 000 27424
UPC: 6 09585 12667 1

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com