

Philips  
DVD Micro Theater

MCD288



## Super-sleek design with superb movie enjoyment

Pure power meets ultra-sleek chic with the MCD288 DVD Micro Theatre that lets you enjoy your favorite music and movies in unmatched sound quality. This elegant beauty will enhance any interior, with option of table-stand or wall-mount.

### **Enrich your movie experience**

- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Dolby Digital for ultimate movie experience
- Progressive Scan component video for optimized image quality

### **Unlimited listening pleasure**

- Enjoy MP3/WMA music directly from your portable USB devices

### **Enrich your sound experience**

- Class 'D' digital amplifier for quality sound performance
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Loudness for bass and treble enhancement
- Total 100W RMS

### **Design that blends into your interior(s)**

- Super sleek and flexible wall-mountable design
- High quality remote control for comfortable use

# PHILIPS

# Highlights

## USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

## Class 'D' Amplifier

Class 'D' Digital Amplifier takes an analog signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output delivers all the advantages of digital audio, including improved sound quality. In addition, Class 'D' Digital Amplifier has greater than 90% efficiency compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can

enjoy consistent sound even when you turn down the volume.

## Loudness for bass and treble

In the sound spectrum, high and low frequencies are relatively less audible to human ears - especially at low volumes. By activating the Loudness feature, the bass and treble will be amplified so you can savor a more balanced sound perception overall.

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.



# Specifications

## Sound

- Output Power: Total 100W RMS
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost, Loudness, Class "D" Digital Amplifier
- Sound System: Dolby Digital

## Loudspeakers

- Main Speaker: 3" woofer, Bass Reflex Speaker System
- Subwoofer type: Active

## Video Playback

- Playback Media: DVD, DivX, DVD+RW, DVD-Video, Video CD/SVCD, Picture CD
- Disc Playback Modes: A-B Repeat, Angle, PBC, Slow Motion, Zoom, Parental control
- DVD Region.: 3
- Loader Type: Slot
- Video Enhancement: Progressive Scan

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, WMA-CD, MP3-CD
- Disc Playback Modes: Repeat/one/all/program, Shuffle Play, 20-Track Programmable
- ID3-tag support
- Loader Type: Slot

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Station presets: 20
- Tuner Enhancements: Auto Store

## Connectivity

- Aux in: Line-in, 3.5 mm
- Headphone: 3.5 mm
- Other connections: FM Antenna, Active subwoofer Pre-out, Digital audio coaxial out
- Video Output - Analog: Component Y Pb Pr (cinch), Composite CVBS (yellow cinch), S-Video (on Hosiden)
- USB: USB host

## Convenience

- Alarms: CD Alarm, Sleep timer
- Clock: On main display
- Display Type: VFD display
- OSD Languages: English, Traditional Chinese
- Indications: DIM mode
- Wall mountable / Ceiling Throw: Wall Mountable

## Accessories

- Included Accessories: FM/MW Antenna, Screws for wall mounting x2, Composite video cable (Y), Audio Cable
- Remote control: 47-key with 2xAAA batteries

## Dimensions

- Set dimensions (W x H x D): 200 x 250 x 110 mm
- Main speaker dimensions (W x H x D): 140 x 220 x 33 mm
- Packaging dimensions (W x H x D): 480 x 244 x 370 mm
- Subwoofer dimensions (W x H x D): 170 x 197 x 302 mm
- Weight incl. Packaging: 13 kg



Issue date 2021-08-16

Version: 2.2.6

12 NC: 9073 100 13067  
EAN: 87 10895 93135 9

© 2021 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Music with Digital Right Management not supported.