

Philips  
Micro Hi-Fi System

MP3/WMA-CD playback  
USB Direct

MCM760



## Digital Music with CD Ripping

Rip and relish your favorite CDs to MP3 player on the elegant MCM760 Micro Hi-Fi System with superb sound. Easy, one touch recording - without a PC! And you can enjoy your favourite music on your portable MP3 player.

### Unlimited listening pleasure

- Rip your favorite CDs to MP3
- One touch MP3 digital recording, no computer needed
- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW

### Enrich your sound experience

- Neodymium Ribbon Tweeter for impressive audio fidelity
- Incredible Surround™ for enhanced audio enjoyment
- Treble and Bass Control for easy high and low tone settings
- 150W RMS total output power

### Refined in sound and look

- Elegant wood-finished speakers

# PHILIPS

# Highlights

## Rip your favorite CDs to MP3

Simply plug in your USB mass storage device to the USB port on Philips audio system and start recording your favorite music from CDs to your USB device or MP3 player - with one touch and no computer needed. So you can create your own MP3 files via direct MP3 digital recording.

## USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

## Neodymium Ribbon Tweeter

The Neodymium Ribbon Tweeter is a monopole tweeter that produces dynamic and crisp sound from the front. It is a feature

commonly used in high-end audio systems to reproduce sound with excellent fidelity. Conventional cones and dome tweeters are based on a directional moving coil principle whereas the monopole Neodymium Ribbon Tweeter radiates high frequencies in a full 180-degree radiation pattern. This dramatically increases the width of the sound spectrum in the higher tones and expands the sweet spot zone to deliver wide, crystal-clear, and natural sound even from compact audio systems.

## Incredible Surround™

Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left and right in such a way that it expands the virtual distance between the two speakers.

This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.

## Treble and Bass Control

Treble and bass are equalizer features that control the high and low frequency sound levels of your audio respectively. Treble specifically regulates the amplification of the high tones in the music while bass controls the amplification level of the low tones. Using the up and down keys, the listener can conveniently place more or less emphasis on the low and high tones, or leave treble and bass flat to playback music according to its original recorded setting. Treble and Bass Control lets you listen to your music the way you like it.



# Specifications

## Sound

- Output power (RMS): 2 x 75W RMS
- Output Power: 2x150 watts music power
- Sound Enhancement: Incredible Surround, Treble and Bass Control

## Loudspeakers

- Main Speaker: 2 way, Bass Reflex Speaker System, 5.25" woofer, Ribbon tweeter, Speaker grilles detachable

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 99-Track Programmable, Shuffle Play, Repeat one/album/all
- ID3-tag support
- Loader Type: Motorised, Tray
- Cassette Deck Technology: Full Logical
- Cassette Playback Modes: Autoreverse, Electronic Speed Control, Full Auto Stop, Tape Counter

## Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: Automatic Recording Level, CD Synchro Start Recording, One-Touch Recording

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- RDS: Station Name, Program Type, Radio Text,

RDS Clock Set, News

- Station presets: 40
- Tuner Enhancements: Auto Store, Easy Set (Plug & Play)

## Connectivity

- Aux in: Line in
- Headphone: 3.5 mm
- Other connections: FM Antenna, MW Antenna
- USB: USB host

## Convenience

- Alarms: CD Alarm, Radio Alarm, Tape alarm, Snooze, Sleep timer
- Clock: On main display
- Display Type: White FTD
- Indications: DIM mode
- Eco Power Standby: 1 watt

## Accessories

- Included accessories: AC Power Cord, FM/MW Antenna
- Remote control: 32-key with 2xAA Batteries

## Dimensions

- Set dimensions (W x H x D): 179 x 252 x 340 mm
- Main speaker dimensions (W x H x D): 175 x 252 x 196 mm
- Packaging dimensions (W x H x D): 524 x 353 x 408 mm
- Weight incl. Packaging: 13.2 kg



Issue date 2014-02-06

Version: 2.0.8

12 NC: 9073 100 13203  
EAN: 87 10895 94508 0

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Music with Digital Right Management not supported.