

Philips
Micro Hi-Fi System

MP3/WMA-CD playback
USB Direct

MCM239



Rich sound in compact design

with USB Direct playback

Great sound in a compact, elegant design! The classic MCM239 delivers dynamic sound performance and the essential functionalities that will let you enjoy music just the way you like it.

Unlimited listening pleasure

- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW
- Convenient line-in jack for portable music playback

Enrich your sound experience

- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimized music style settings
- 400W PMPO / 10W RMS total power

Start the day your way

- Digital tuning with 40 preset stations for extra convenience
- Wake up and sleep timer functions

PHILIPS

Highlights

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a

button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges

for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



Specifications

Sound

- Output power (RMS): 2 x 5W
- Output Power: 400 W PMPO
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost

Loudspeakers

- Main Speaker: Bass Reflex Speaker System, 4" woofer, Full range

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Repeat/one/all/program, Shuffle Play, 20-Track Programmable
- Loader Type: Front
- ID3-tag support
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store

Connectivity

- Aux in: 3.5 mm

- Headphone: 3.5 mm
- Other connections: FM Antenna, MW Antenna
- USB: USB host

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer, USB alarm
- Clock: On main display
- Display Type: LCD
- Backlight color: Blue

Accessories

- Included accessories: FM/MW Antenna, Stand, World Wide Warranty leaflet
- Remote control: 24-key with Lithium batteries
- AC/DC Adaptor: Switching power supply
- User Manual: Spanish, Brazilian Portuguese
- Quick start guide: Spanish, Brazilian Portuguese

Dimensions

- Set dimensions (W x H x D): 211 x 250 x 160 mm
- Main speaker dimensions (W x H x D): 158 x 250 x 118 mm
- Packaging dimensions (W x H x D): 350 x 310 x 284 mm
- Weight incl. Packaging: 3.8 kg

Power

- Power supply: 100-240VAC, 50/60Hz



Issue date 2014-02-07

Version: 3.0.3

12 NC: 8670 000 38239
EAN: 87 12581 40511 3

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Avoid extensive use of the set in a volume higher than 85 decibel
because this may damage your hearing.