

PHILIPS

Wireless Hi-Fi Headphone

32 mm drivers/closed-back

Over-ear

SHC5200



Wireless freedom

Fully rechargeable wireless headphones

No more hassles with the cables, you can feel free to move around at home for music enjoyment. With the rechargeable and lightweight design of these Philips SHC5200/05 headphones, you don't need to bother for long wearing time.

Comfortable for long use

- Self-adjusting inner headband
- Lightweight design improves comfort for prolonged use.

The perfect wireless listening experience

- 32 mm speaker driver delivers high-performance sound
- FM Wireless transmission for freedom of movement

Convenience

- Fully rechargeable
- Choose from 2 channels to minimise interference

Specifications

Sound

Frequency range: 10–20,000 Hz
Speaker diameter: 32 mm
Impedance: 24 Ohm
Sensitivity: 100 dB
Distortion (THD): < 2% @1k Hz
Driver type: Dynamic

Connectivity

Wireless
Maximum range: Up to 100 m
Type of wireless transmission: FM
Channel selection: 2
Headphone socket: 3.5 mm

Outer Carton

Length: 32.5 cm
Number of consumer packages: 3
Width: 26 cm
Gross weight: 2.87 kg
Height: 32.5 cm
GTIN: 1 69 25970 70539 1
Net weight: 1.26 kg
Tare weight: 1.61 kg

Convenience

Automatic power off

Power

Rechargeable
Number of batteries: 2 x AAA 1.5 V
Music play time: 14 hour(s)
Battery type (Headphones): NiMH rechargeable batteries

Packaging dimensions

Height: 32 cm
Packaging type: Carton
Type of shelf placement: Both
Width: 24 cm
Depth: 10 cm
Number of products included: 1
EAN: 69 25970 70539 4
Gross weight: 0.754 kg
Net weight: 0.42 kg
Tare weight: 0.334 kg

Product dimensions

Height: 22 cm
Width: 19.5 cm
Depth: 8.5 cm
Weight: 0.178 kg

Accessories

Others: 2 x AAA NiMH batteries, Antenna tube
Docking station (transmitter)
Included adapters: AC/DC adapter

Design

Colour: Black
Wearing style: Headband
Ear coupling material: Fabric
Ear fitting: Over-ear
Earcup type: Closed-back

Highlights

32 mm speaker driver

The 32 mm speaker driver is a compact yet powerful element for delivering non-distorted sound with any given input power.

Self-adjusting inner headband

Typically, headphones worn outdoors are adjustable by sliding an extendable headband into position. This can be inconvenient as it usually has to be done every time you use them. But now you can get your music fix faster and easier thanks to the flexible, self-adjusting inner headband on these headphones, which automatically adjusts to your head's shape and size.

Lightweight design

The durable, lightweight quality materials of these Philips headphones enhance comfort for extended wear.

FM Wireless transmission

With high-frequency FM wireless transmission, which can even pass through walls, you can even listen to your music when you're in another room.

Fully rechargeable

The headphones are designed to be used with rechargeable batteries. No worries about cost for repeated use.

2 transmission channels

With a choice of two transmission channels your listening pleasure is protected because you can easily switch to the one with the best reception.

