

Philips  
DVD player

HDMI 1080p  
DivX Ultra

DVP3980



## Now enjoy high definition video

with true high-def HDMI 1080p

Your dream player with flawless, true-to-life picture quality and the ability to play virtually any disc! The Philips DVD player delivers your movies and music entertainment experience.

### Play all your movies and music

- DivX Ultra Certified for enhanced playback of DivX videos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW
- Plays DivX, MP3, WMA and JPEG digital camera photos

### Bring audio and video to life

- 12-bit/108MHz video processing for sharp and natural images
- Progressive Scan component video for optimized image quality

### Easy to set up and use

- EasyLink to control all HDMI CEC devices via a single remote

### Fits any space, any lifestyle

- Ultra-slim design that fits anywhere

### Bring video to life

- HDMI digital output for easy connection with only one cable

# PHILIPS

# Highlights

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

## DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio

languages, multiple tracks and menus into one convenient file format.

## Plays it all

Play virtually any media format you want - whether they be DivX, MP3s, WMA or JPEGs. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system - in the comfort of your living room.



# Specifications

## Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Video upscaling, Video Upscaling(720p, 1080i/p)

## Sound

- D/A converter: 24 bit, 192 kHz
- Frequency response: 30-20000 Hz
- Signal to noise ratio: 90
- Distortion and Noise (1kHz): 80 dB
- Crosstalk (1kHz): 90 dB
- Dynamic Range (1kHz): 80 dB
- Sound System: Dolby Digital

## Video Playback

- Playback Media: CD, CD-R/CD-RW, Video CD/SVCD, DVD, DVD+R/+RW, DVD-R/-RW, DVD-Video, DivX
- Compression formats: MPEG1, MPEG2
- Video disc playback system: PAL

## Audio Playback

- Playback Media: CD, MP3-CD, MP3-DVD, WMA-CD, CD-R/RW, Audio CD
- MP3 bit rates: 32 - 320 kbps
- Compression format: MP3, Dolby Digital, PCM, WMA

## Still Picture Playback

- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, Picture CD, Kodak Picture CD

- Picture Compression Format: JPEG
- Picture Enhancement: Rotate, Zoom, Slideshow

## Connectivity

- Rear Connections: Analog audio Left/Right out, ComponentVideo out Progressive, Digital coaxial out, HDMI output, Scart

## Convenience

- Child Protection: Child Lock, Parental Control
- On-Screen Display languages: Danish, Dutch, English, Finnish, French, German, Italian, Norwegian, Polish, Portuguese, Spanish, Swedish, Turkish

## Power

- Power supply: 230V, 50Hz
- Power consumption: < 10 W
- Standby power consumption: < 1.0 W

## Accessories

- Included accessories: 2 x AAA Batteries, Audio/Video cable, Remote Control, User Manual, Power cord, Quick start guide, Warranty Leaflet

## Dimensions

- Packaging dimensions (W x H x D): 415 x 82 x 282 mm
- Set dimensions (W x H x D): 360 x 37 x 210 mm

## Multimedia Applications

- Playback Formats: JPEG Still pictures, MP3



Issue date 2017-04-04

Version: 1.0.6

12 NC: 8670 000 38485  
EAN: 87 12581 40814 5

© 2017 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)