



## Tilting wall mount

### LCD

Designed to fit most brands of TV with a focus on safety & ease of use. Easy 1-2-3 installation kit includes necessary hardware for different wall types, templates, stud finder, bubble level. UL certified for weight capacity up to 55 lbs.

#### Enhances viewing angle

- + / - 15° tilt

#### Fits most TV brands

- VESA 75,100,100x200,200
- UL/CUL approved for weight capacity
- Screen sizes 58 - 94 cm (23" - 37")

#### Easy installation

- Mounting templates included
- Mounting hardware included
- Bubble level and stud finder
- Max hole pattern 800 x 500 mm
- Max hole pattern 800 x 510 mm

Philips  
LCD wall mount

Tilting



SQM4732



# PHILIPS

# Specifications

## Packaging dimensions

- Packaging dimensions (W x H x D): 25.5 x 29.8 x 5.5 cm
- Packaging dimensions (W x H x D): 10.039 x 11.75 x 2.165 inch
- Nett weight: 1.300 kg
- Nett weight: 2.866 lb
- Gross weight: 1.520 kg
- Gross weight: 3.35 lb
- Tare weight: 0.220 kg
- Tare weight: 0.484 lb
- Number of products included: 1
- Packaging type: Carton
- UPC: 6 09585 14913 7

## Outer Carton

- Outer carton (L x W x H): 52.1 x 26.4 x 12.5 cm
- Outer carton (L x W x H): 20.5 x 10.4 x 4.92 inch
- Nett weight: 5.200 kg
- Nett weight: 11.464 lb
- Gross weight: 6.600 kg
- Gross weight: 14.55 lb
- Tare weight: 1.400 kg
- Tare weight: 3.086 lb
- GTIN: 1 06 09585 14913 4
- Number of consumer packagings: 4

# Highlights

## + / - 15° tilt

Allow the TV to be adjusted up and down + / - 15° to attain the optimum viewing angle.

## VESA 75,100,100x200,200

Compliance with the Video Electronics Standards Association requirements for bolt patterns ensures that the wall support matches up to the bolt pattern on your specific TV.

## UL/CUL weight approved

Compliance with Underwriters Laboratories requirements for weight certification ensures the wall mount will safely hold your TV.

## Mounting templates included

Paper guides indicate the ideal hole pattern for drilling into walls, ensuring users of exactly the right hole configuration.

## Mounting hardware included

Includes all necessary screws, anchors and bolts for different types of walls, ensuring the right type of hardware is readily available for the particular type of wall the support is being mounted on.

## Bubble level and stud finder

Includes both tools necessary for installation. A bubble level ensures a straight line. A stud finder quickly, easily and accurately locates studs in the wall.



Issue date 2016-07-25

Version: 2.1.4

12 NC: 8670 000 37255  
UPC: 6 09585 14913 7

© 2016 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)