

Philips CD Soundmachine with Dynamic Bass Boost

AZ1226







# all-in-one, MP3 music with enriched bass

You take pleasure in the simple things in life and delight in convenience. The sleek and portable AZ1226 lets you indulge in the pleasures of enjoying your favorite music in enriched bass sound with the help of easy-to-use functions.

# Feature-packed CD player

- MP3-CD,CD-R/RW compatible
- CD shuffle/program/repeat

# **Enhanced bass performance**

- Bass Reflex speakers deliver a powerful, deeper bass
- Dynamic Bass Boost for deep and dramatic bass
- 4 full range speakers

# Easy to use

- · CD to tape synchro-start recording
- Multi-functional LCD display
- · Stereo headphone socket



# Sound

- Output power (RMS): 2XI.2W
- Sound System: Stereo

**Specifications** 

- Volume Control: rotary
- Loudspeaker types: Bass Reflex Speaker System
- Speaker diameter: 4"
- Sound Enhancement: Dynamic Bass Boost

# **Audio Playback**

- Loader Type: Top
   Playback Media: CD, CD-R, CD-RW, MP3-CD
   Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Programmable Tracks: 20
- Number of decks: I
- · Cassette Deck Technology: Mechanical

# Tuner/Reception/Transmission

- Antenna: AM antenna, FM Antenna
  Tuner Bands: FM, MW

# Connectivity

Headphone: 3.5 mm

# Convenience

· Display Type: LCD

#### Accessories

· Included Accessories: AC Power Cord, User Manual, Warranty certificate

## **Power**

- Mains power
- Battery type: LR14
- Battery voltage: I.5 V
- Number of batteries: 6

### **Dimensions**

- Packaging dimensions (W x H x D): 470 x 210 x 290 mm
- Product dimensions (W x H x D):  $400 \times 162 \times 238 \text{ mm}$
- Weight: 2.9 kg
- · Weight incl. Packaging: 3.7 kg

# **Product highlights**

# MP3-CD,CD-R/RW compatible

# CD shuffle/program/repeat

# **Bass Reflex Speaker System**

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

# **Dynamic Bass Boost**

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high — at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

4 full range speakers

CD synchro-start recording

Multi-functional LCD display

Stereo headphone socket



Issue date 2007-12-06

Version: 4.0

© 2007 Koninklijke Philips Electronics N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 9073 101 01909 EAN: 87 10895 88240 8

www.philips.com