

Philips Cube micro sound system Dock for iPod DCM105



Obsessed with sound

Sound that fits your home

Dock your iPod player. Listen to your music from one simple control. Great sound and stylish design. Sit back and relax, enjoy your music all day, your way.

Enjoy your favorite music

- iPod music playback and recharge
- Play CD, CD-R and CD-RW
- FM digital tuning with presets

Superb sound quality

- Dynamic Bass Boost for deep and dramatic sound
- 10W RMS total output power

Design that blends into your interior

- Compact design fits any space, any lifestyle
- Integrated dock for portable music enjoyment without clutter



Specifications

Audio playback

- Playback media: CD, CD-R, CD-RW
- Disc playback modes: repeat/shuffle/program
- Docking playback modes: fast forward and backward, next and previous track, play and pause

Sound

- Output power: 2 x 5 W RMS
- Sound enhancement: Dynamic Bass Boost, digital sound control
- Volume control: up/down

Loudspeakers

- Speaker drivers: 3.5" woofer
- · Speaker types: bass reflex speaker system

Tuner/Reception/Transmission

• Tuner bands: FM stereo

Connectivity

- Audio/Video output: Headphone (3.5mm)
- MP3 Link: 3.5mm stereo line in

Convenience

- Alarms: CD alarm, radio alarm
- Loader type: top
- Clock: on main display, sleep timer









• Display type: LCD display

- Backlight color: white
- · Charging device: iPod

iPod compatibility

 Compatible with: iPod, iPod mini, iPod nano, iPod touch, iPod with color display, iPod 5th generation

Accessories

- Cables/Connection: MP3 Link cable
- User Manual: multi-languages
- Warranty: World Wide Guarantee booklet

Dimensions

- Gross weight: 5.48 kg
 Main speaker dimensions (W x D): 150 x 197 mm
- Main speaker height: 152 mm
- Main unit depth: 250 mm
- Packaging width: 531 mm
- Main unit height: 152 mm
- Packaging height: 302 mm
- Packaging depth: 202 mm
- Main unit width: 150 mm

Power

- Power supply: 220 240 V
- Power supply: 50 Hz

DCM105/12

Highlights

iPod music playback iPod music playback and recharge

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings from low to high – at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

