

Philips
Blu-ray Disc player



BDP7200



Defining the world of high definition

with Blu-ray disc playback

Enjoy the thrill of full high definition pictures delivered by the BDP7200. Indulge in every detail, silky smooth action and vivid colors with Deep Colour. Current DVD favorites can also be enjoyed, with upscaling to 1080p via HDMI.

See more

- Blu-ray Disc playback for sharp images in full HD 1080p
- Deep Color for vivid images in over a billion colors
- 1080p at 24 fps for cinema-like images
- Full HD 1080p for razor sharp images
- Bonus View with Picture-in-Picture for video & audio choices
- Flawless undistorted video with MPEG and 3D noise reduction
- DVD video upscaling to 1080p via HDMI for near-HD images

Hear more

- Dolby TrueHD and DTS-HD for high fidelity 7.1 surround sound

Engage more

- Enjoy all your movies and music from CD and DVD
- EasyLink to control all HDMI CEC devices via a single remote

PHILIPS

Highlights

Blu-ray Disc playback

Blu-ray Discs have the capacity to carry high definition data, along with pictures in the 1920 x 1080 resolution that defines full high definition images. Scenes come to life as details leap at you, movements smoothen and images turn crystal clear. Blu-ray also delivers uncompressed surround sound - so your audio experience becomes unbelievably real. The high storage capacity of Blu-ray Discs also allow a host of interactive possibilities to be built in. Seamless navigation during playback and other exciting features like pop-up menus bring a whole new dimension to home entertainment.

Bonus View

With Bonus View, you can enjoy picture-in-picture with audio choices. A second smaller window - which runs a separate video sequence, appears over the main picture. You can then choose whether you want to listen to what's going on in the smaller window or in the larger one. This allows you to enjoy many special features that are often included in Blu-ray Disc movies. For example, you can watch and listen to the director's comments in the smaller window, whilst he points to scenes or actors in the main picture.

Full HD 1080p

Blu-ray Discs have the capacity to carry high definition data, along with pictures in the 1920

x 1080 resolution that defines full high definition images. This can only mean you get the best possible TV picture quality available today - so prepare to feast your eyes.

Deep Color

The real world is not limited by colors - practically any hue can occur in any shade, in any luminosity. What you see on your TV screen is a different matter, so images often don't look true to life. Deep Color recreates the natural world on your TV screen, bringing to you the millions and millions of colors that occur in reality - and launching your viewing experience to new heights.

1080p at 24 fps

Bring true cinema experience into your living room with 24 frames-per-second video. Original films are all recorded at this frame rate, providing an ambience and image texture that is so unique. Philips Blu-ray Disc players are equipped to bring you 24fps directly from Blu-ray Discs - thus giving you sensational cinema-like high definition images that will astound you.-

EasyLink

EasyLink lets you control multiple devices like DVD players, Blu-ray players, soundbar speaker, Home theater and TV's etc. with one remote. It uses HDMI CEC industry-standard

protocol to share functionality between devices through the HDMI cable. With one touch of a button, you can operate all your connected HDMI CEC enabled equipment simultaneously. Functions like standby and play can now be carried out with absolute ease.

Flawless undistorted video

Cameras taking still and moving images pick up aberrations (or noise) from a variety of sources. These, though not individually visible, contribute to poor picture quality. The MPEG and 3D noise reduction feature cleans the picture up - so you can be assured of crystal clear images every time.

DVD video upscaling

HDMI 1080p upscaling delivers images that are crystal clear. DVD movies in standard definition can now be enjoyed in high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multi-channel audio, without conversions to analog - delivering perfect picture and sound quality, completely free from noise.



BONUS VIEW

HDMI



Specifications

Picture/Display

- D/A converter: 12 bit / 150MHz
- Picture enhancement: Progressive scan, Video upscaling, High Def (720p, 1080i, 1080p)
- Aspect ratio: 16:9, 4:3

Sound

- D/A converter: 24 bit, 192 kHz
- Dynamic Range (1kHz): 100 dB
- Frequency response: (20kHz) ± 0.5 dB (Max./Min. 2ch, DVD) Hz
- Signal to noise ratio: 120 dB
- Sound System: Dolby Digital, DTS

Video Playback

- Playback Media: CD-R/CD-RW, DVD-Video, DVD-R/-RW, CD, DVD+R/+RW, DVD, BD Video, BD-R/RE 2.0, BD-ROM
- Compression formats: MPEG2, H.264, VC-1
- Video disc playback system: NTSC, PAL
- Disc Playback Modes: A-B Repeat, Angle, Disc Menu, Pause, Repeat, Resume Playback from Stop, Skip, Search forward/reverse, Slow Forward, Standard Play, Zoom
- DVD Region.: 2
- Picture Quality Enhancements: Video upscaling
- Video Enhancement: Progressive Scan, Video Upscaling

Audio Playback

- Playback Media: MP3-CD, CD-R/RW, CD, MP3-DVD
- Compression format: MP3, PCM, Dolby Digital, DTS
- Multichannel decoding: Dolby Digital

Still Picture Playback

- Playback Media: CD-R/RW, DVD+R/+RW, DVD-

R/-RW

- Picture Compression Format: JPEG
- Picture Enhancement: Slideshow, Rotate, Zoom, High Definition Resolution

Multimedia Applications

- Playback Formats: JPEG Still pictures, MP3

Connectivity

- Rear Connections: Analog audio Left/Right out, Analog audio Multi-channel out, Component Video output, Composite video (CVBS) output, Digital coaxial out, HDMI output

Convenience

- On-Screen Display languages: Dutch, English, French, German, Italian, Portuguese, Spanish
- Child Protection: Parental Control

Accessories

- Included accessories: Audio Cable, Quick start guide, IFU / User Manual, Product Registration Card, 2 x AA Batteries, Remote Control, HDMI cable
- User Manual: English, French, German, Spanish, Dutch, Italian, Portuguese

Power

- Power supply: 110-240V, 50Hz
- Power consumption: 30 W
- Standby power consumption: 0.2W

Dimensions

- Set dimensions (W x H x D): 435 x 70 x 348 mm
- Set weight: 4.2 kg
- Packaging dimensions (W x H x D): 543 x 178 x 458 mm
- Weight incl. Packaging: 6.4 kg



Issue date 2015-09-03

Version: 2.0.8

12 NC: 8670 000 42009
EAN: 87 12581 44103 6

© 2015 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com