

Philips
Cube micro sound system



MCM103

Obsessed with sound

Relax with great music

Enjoy your favorite CDs and portable music just the way you like it. The Philips cube micro music system plays CDs and more, it also features USB Direct for portable music playback. The compact design fits any space, any lifestyle.

Enjoy your favorite music

- Play MP3/WMA-CD, CD and CD-RW
- USB Direct for easy MP3 music playback
- FM digital tuning with presets

Superb sound quality

- Dynamic Bass Boost for deep and dramatic sound
- 10W RMS total output power

Design that blends into your interior

- Compact design fits any space, any lifestyle

PHILIPS

Specifications

Sound

- Output power: 2 x 5 W RMS / 400 W PMPO
- Sound enhancement: Dynamic Bass Boost, digital sound control
- Volume control: up/down

Loudspeakers

- Speaker drivers: 3.5" woofer

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/shuffle/program
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, program play, repeat, shuffle, stop

Tuner/Reception/Transmission

- Tuner bands: FM stereo
- Station presets: 20
- Antenna: FM fixed pigtail antenna
- Tuner enhancement: auto digital tuning, auto scan

Connectivity

- Audio/Video output: Headphone (3.5mm)
- MP3 Link: 3.5mm stereo line in

Convenience

- Alarms: CD alarm, radio alarm
- Clock: on main display, sleep timer
- Loader type: top
- Display type: LCD display
- Backlight color: white

Accessories

- Remote control
- Others: FM/MW antenna, Quick start guide
- User Manual: English, Traditional Chinese

Dimensions

- Gross weight: 4.58 kg
- Main speaker dimensions (W x D): 150 x 197 mm
- Main speaker height: 152 mm
- Main unit depth: 250 mm
- Packaging depth: 206 mm
- Main unit height: 152 mm
- Packaging height: 310 mm
- Main unit width: 150 mm
- Packaging width: 530 mm

Power

- Power supply: 100 - 240V AC, 50/60Hz



Highlights

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Play MP3/WMA-CD, CD and CD-RW



Audio compression technology allows large digital music files to be reduced up to 10 times in size without radically degrading their audio quality. MP3 or WMA are two of the compression formats that let you enjoy a world of digital music on your Philips player. Download MP3 or WMA songs from authorized music sites on the Internet or create your own MP3 or WMA music files by ripping your audio CDs and transferring them onto your player.

USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.



Issue date 2014-02-12

Version: 2.0.5

12 NC: 8670 000 56727
EAN: 87 12581 50855 5

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com