

Philips docking entertainment system

DAB radio

dual alarms MP3 Link

DCB310

Superb sound quality for iPod and DAB

wOOx technology for powerful bass

Free your iPod music in superb sound with the Philips Docking entertainment system DCB310. The interference-free DAB radio feature brings you crystal clear sound quality. Thanks to wOOx technology for a dramatically enhanced bass.

Rich and clear sound

- Play and charge your iPod simultaneously
- DAB for clear and crackle-free radio experience
- wOOx $^{\text{TM}}$ loudspeaker Technology for deep and powerful bass

Start the day your way

- Wake up to your favorite iPod music
- · Dual alarm time
- Gentle wake for a pleasant wake up experience

Easy to use

- 10 preset tuning stations
- Convenient line-in jack for portable music playback
- Sleep timer for easy falling asleep to your favorite music



Highlights

DAB

DAB (Digital Audio Broadcasting) digital radio is, on top of FM analog transmission, a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear and crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can be find. With DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no returning on the move.

wOOx™ Technology

wOOx technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical sandwich construction deliver low and precise base without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.

Wake up to iPod music

Wake up to your favorite iPod music

10 preset tuning stations

10 preset tuning stations

Convenient line-in jack

Line-in connection allows you to play your music on other device with the Philips player, just simply connect the player to the Line-out or Audio-out, or to connect the headphone jack of other media players such as CD or DVD player, VCR and MP3 player.















Specifications

iPod compatibility

• Compatible with: iPod mini, iPod with color display, iPod 5th Generation, iPod classic, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod touch

Audio Playback

· Cradle playback mode: Charging iPod, Play and Pause, Next and Previous track, Fast forward and

Tuner/Reception/Transmission

- DAB: Band III, Info display, Menu, Smart Scan
- Tuner Bands: FM
- Auto digital tuning
 RDS: Radio Text, Station Information, Station
- · Antenna: FM Antenna • Station presets: 15

Loudspeakers

- Built-in speakers: 3
- Loudspeaker Enhancement: wOOx Bass Radiator
- Neodynium magnet system

Convenience

· Clock/Version: Digital

- · Alarms: 24 hour alarm reset, Dual alarm time, Buzzer Alarm, Radio Alarm, Repeat alarm (snooze), Sleep timer
- Display Type: LCD
- Backlight
- Backlight color: White

- Output power (RMS): 2 x 3W
- Sound System: Stereo
- Volume Control: Volume Control up/down

Connectivity

· Aux in: Line-in, 3.5 mm

Power

- Mains power
- Adaptor type: 100-240V 50/60Hz

Dimensions

- Product dimensions (W \times H \times D): 161 x 191 x 164 mm
- Weight: 1.34 kg
- Packaging dimensions (W x H x D): 248 x 224 x 212 mm
- Weight incl. Packaging: 1.94 kg



Issue date 2014-02-07

Version: 1.0.3

© 2014 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 42683 EAN: 87 12581 44636 9

www.philips.com