

Philips
Multimedia Speakers 2.0

MMS221

Stereo sound you can trust

Authentic sound for multimedia enjoyment

The easy way to add an authentic stereo experience to your music, Internet and multimedia PC applications is with the MMS221 Harmonic Pulse speaker system with its class-leading bass performance.

Your computer never sounded so good

• Enjoy PC audio with the quality of a home audio system

Experience true multimedia

- · Compatible with music, games, film & internet audio sources
- Easy to connect to either a PC or a laptop

Hear every detail

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Digital Dynamic Bass Boost for optimized bass at any volume

Easy to use

- Labelled and color-coded connectors get you going in minutes
- Magnetic Shielding eliminates computer screen distortion



Specifications

Sound

- · Bass enhancement: Digital Bass Boost
- Frequency response: 120 20 000 Hz
- Output power (RMS): 2 x 1.5W
- Music Power: 6 W
- Volume Control: Analogue Volume Control
- · Wires: Fixed Wires

Loudspeakers

• Loudspeaker Enhancement: Magnetic Shielded LSB



Connectivity

- Headphone: 3.5 mm
- · Power: Built-in transformer

Convenience

· Power on indication

Accessories

· Included accessories: Quick install guide



Home audio quality on the PC

Philips has used over 75 years experience at the leading edge of audio to create PC audio products with the same performance as our award-winning home audio systems.

Music, games, films, internet

All types of music, games, films and internet audio sources can be played, so no matter what you want to hear, we make your multimedia experiences sound more involving than ever.

For PC or Laptop

Can be connected to either a PC or a laptop

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Digital Dynamic Bass Boost

Digital Dynamic Bass Boost is an intelligent bass booster that delivers maximum bass enhancement at high volumes without sound distortion and at low volumes without compromising on bottom-end bass frequencies. Technologically advanced electronics constantly monitor volume and bass levels, precisely calibrating both to prevent sound distortion, thus producing optimized bass. Digital Dynamic Bass Boost enables the enjoyment of superb bass performance - regardless of the chosen volume level.

Quick set-up

Color-coded cables, clear labelling and easy to understand documentation mean you'll be up and running in minutes

Magnetic Shielding

Because the powerful magnets in speaker drivers are magnetically shielded, there"s no danger of image distortion or damage when placed close to your PC monitor screen.



Issue date 2014-02-06

Version: 4.0.5

© 2014 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 9306 000 00078 EAN: 87 10895 53074 3

www.philips.com