

PHILIPS

矩阵切换器

1000 Series

TAI1134/93



www.philips.com/welcome



2021 © MMD Hong Kong Holding Limited. All rights reserved. Specifications are subject to change without notice.

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of MMD Hong Kong Holding Limited or one of its affiliates, and MMD Hong Kong Holding Limited is the warrantor in relation to this product.

TAI1134/93



产品概述

TAI1134/93是一款4K高清HDMI矩阵切换器，由8路HDMI输入与8路HDMI输出组成，形成8x8矩阵切换器。每路HDMI输出分别带有1路数字同轴音频输出。支持HDMI标准，兼容HDCP，支持4Kx2K、1080P 3D分辨率。智能化EDID管理，内置10种EDID数据。设备控制方式灵活多样，涵括红外控制、串口控制、网口控制、面板按键控制，能同时兼容控制，使用更方便。

功能说明

- **高清分辨率：**4Kx2K@60Hz，支持1080P 3D，2560×1080输入支持HDMI2.0标准，向下兼容HDMI1.4、HDMI1.3，兼容HDCP2.2标准，输出支持HDMI1.4标准，兼容HDCP1.4标准传输4Kx2K信号达15米远距离。

两种EDID管理形式：软件管理（指令实现）、硬件管理（拨码开关实现）内置10种EDID数据，输入HDCP跟随，输出支持HDCP管理：指令控制，支持场景保存功能（指令控制）
USB固件在线升级

控制方式多样：前面板按键、IR红外、RS232串口、TCP/IP网口断电记忆功能，避免重复性设置

注意事项

- 为确保正确使用本产品，墙面开关必须由专业电工安装拆卸
- 安装或拆卸墙面开关前必须要切断电源总闸，以防触电
- 安装或拆卸本产品所控制的灯或灯具前必须要切断电源总闸以防触电
- 本产品在安装和使用过程中需要远离火源和水源
- 本产品不能在潮湿环境中使用（比如浴室）

技术参数

产品名称	矩阵切换器
额定电压	DC 24V, 2.5A
输入	8路 HDMI
输出	8路 HDMI, 8路 SDPIF数字音频
支持分辨率	最高支持4Kx2K、 支持1080P 3D、2560x1080
传输距离	4Kx2K≤15米
工作温度	0°C~50°C
工作湿度	≤90%RH (无冷凝)
通讯协议	RS485, TCP/IP
产品尺寸	141mmx87mmx8.7mm

使用说明

