DOCEMBLE FOR THE PROPERTY OF T

Philips
DVD Micro Theater

MCD515

Rich Sound and Movie Experience

You're in touch with the latest and the coolest - now get a load of the hot Micro Theatre with DVD, DivX and MP3-CD/WMA-CD playback! Relax to your favorite movies and music. Home entertainment will never be the same again!

Enrich your movie experience

- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- · Dolby Digital for ultimate movie experience

Enrich your sound experience

- Incredible Surround[™] for enhanced audio enjoyment
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2x25W RMS/1000W PMPO

Start the day your way

- Wake up and sleep timer functions
- · Logic tape deck
- Digital tuning with 40 preset stations for extra convenience

Your personal karaoke show

· Karaoke for endless singing entertainment



Highlights

Incredible Surround™

Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume

settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Karaoke

The Karaoke feature on your DVD player provides endless entertainment and maximum audio and singing enjoyment. You can enhance your performance by adding an 'echo' effect to your voice. The key controls allows you to choose the optimal key for your personal vocal

















Specifications

Sound

- Output Power: 2x25 W RMS / 1000W PMPO
- Sound Enhancement: Incredible Surround, Digital Sound Control 4 modes, Dynamic Bass Boost
- Sound System: Dolby Digital

Loudspeakers

 Main Speaker: 2 way, Bass Reflex Speaker System, 4" woofer, Piezo tweeter, Speaker grilles detachable

Video Playback

- Playback Media: DVD+RW, DVD-Video, Video CD/SVCD, Picture CD, DivX
- DVD Region.: 3
- Disc Playback Modes: Zoom, Slow Motion, A-B Repeat, Angle, Parental control, PBC
- · Loader Type: Top

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Repeat/one/all/program, Shuffle Play, 16-Track Programmable
- Cassette Deck Technology: Logic
- Cassette Playback Modes: Electronic Speed Control

Audio Recording

- · Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording, Automatic Recording Level, One-Touch Recording

Tuner/Reception/Transmission

- Tuner Bands: MW, FM Stereo
- · Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store

Connectivity

- Aux in: 1x(L/R)/RCA
- Video Output Analog: Component Y Pb Pr (cinch), S-Video (on Hosiden), Composite CVBS (yellow cinch)
- · Headphone: 3.5 mm
- Other connections: Active subwoofer Pre-out, Line out, FM Antenna, MW Antenna, Digital coaxial out

Convenience

- · Alarms: Sleep timer
- Clock: On main display
- OSD Languages: English, Traditional Chinese
- Display Type: VFD display
- Karaoke: Key control, MIC volume, Echo control

Accessories

- Included accessories: Composite video cable (Y), Audio Cable, FM/MW Antenna
- Remote control: 45-key with 2xAA batteries

Dimensions

- Set dimensions (W \times H \times D): 175 \times 252 \times 305 mm
- Main speaker dimensions (W x H x D): 170 x 252 x 214 mm
- Packaging dimensions (W x H x D): 528 x 351 x 400 mm
- Weight incl. Packaging: 10.5 kg



Issue date 2011-07-21

© 2011 Koninklijke Philips Electronics N.V. All Rights reserved.

Version: 2.0.4

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 9073 100 13091 EAN: 87 10895 93815 0

www.philips.com