

Philips Portable Speaker System

# SBP1150



# Portable

# Small & lightweight

Delight your friends by sharing your music with these handy, powerful & compact speakers. Take them anywhere to plug & play with your MP3, your CD player or your laptop.

# For superb music pleasure

- · Powerful speaker drivers for ultra realistic sound
- · Bass pipe emphasizes low tones for a clear, realistic sound
- Wide stereo sound stage when speakers placed apart.

# Share your music anywhere

- Small and lightweight for carrying in your pocket or bag
- Universal use with all portable entertainment equipment

### Always ready to go

- No batteries required for extra convenience
- Plug & play with all portable music devices



# Specifications

#### Sound

- Frequency response: 100 18 000 Hz
- · Impedance: 8 ohm
- RMS Power rating: 2 x 1 W
- Speaker diameter: 50mm

## Connectivity

- Cable length: 1.2 m
- Connector: 3.5 mm stereo
- Finishing of connector: Chrome plated
- Convenience
- · Operating time: No Batteries Required

## **Accessories**

• AC/DC Adaptor: No

#### Power

- Adaptor type: N/A
- Battery voltage: 0 V
- Number of batteries: 0

#### **Packaging dimensions**

- Packaging dimensions (W x H x D):
- 4.4 x 7.5 x 3.2 inch
- Gross weight: .864 lb
- Nett weight: .694 lb
- Tare weight: .17 lb

#### **Outer Carton**

- · Gross weight: 23.876 lb
- Outer carton (L x W x H): 19.2 x 10.8 x 15 inch
- Nett weight: 16.667 lb
- Tare weight: 7.209 lb

### **Inner Carton**

- Gross weight: 5.6 lb • Inner carton (L x W x H):  $10.1 \times 9.2 \times 7$  inch
- Nett weight: 4.167 lb • Tare weight: 1.433 lb

# SBP1150/37

# Highlights

#### **Powerful speaker drivers**

Powerful speaker drivers produce ultra realistic sound, totally immersing you in the game.

#### **Bass Pipe**

Thanks to an acoustically-tuned air channel that turbo-charges the bass notes, you enjoy fantastic realism and a truly involved listening experience.

#### Wide stereo soundstage

These portable speakers create a natural stereo sound stage when they are a placed apart, this gives the impression that each musical instrument occupies a different physical space. The effect is more realistic and more enjoyable.

#### **Compact and lightweight**

Small and lightweight you'll hardly notice it's with you. Pop it in your pocket or bag and take it anywhere.

#### For portable equipment

Universal use with all portable entertainment equipment. Simply connect using the 3.5mm plug.

#### No batteries required

For extra convenience, no batteries are required in these portable speakers. They are powered by the portable audio player's ouyput signal.

#### Plug & play speakers

The 'plug & play' feature saves you time because you simply connect the speakers to the portable audio player as you would normally connect the headphones, by using the jack plug.



Issue date 2013-01-31

© 2013 Koninklijke Philips Electronics N.V. All Rights reserved.

Version: 1.0.4

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 37261 UPC: 6 09585 14917 5

www.philips.com