

Philips
Classic micro Hi-Fi system

Ribbon tweeter
150W

MCM761



Obsessed with sound

Enjoy high fidelity music

Good sound is yours to have with the Philips classic micro hi-fi system. Rip your music directly to an MP3 using the USB Direct. No PC is needed. Elegantly designed with wood-finished speakers for a classic look that won't go out of style.

Multiple sources for more choices

- Rip your favorite CDs to MP3
- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW
- Cassette deck with auto stop

Enrich your sound experience

- Neodymium Ribbon Tweeter for impressive audio fidelity
- Incredible Surround™ for enhanced audio enjoyment
- Treble and Bass Control for easy high and low tone settings
- 150W RMS total output power

Easy to use

- Motorized CD loader for convenience access
- RDS digital tuner with 40 preset stations
- Wake up and sleep timer functions



asimpleswitch.com



asimpleswitch.com

PHILIPS

Highlights

Neodymium Ribbon Tweeter

The Neodymium Ribbon Tweeter is a monopole tweeter that produces dynamic and crisp sound from the front. It is a feature commonly used in high-end audio systems to reproduce sound with excellent fidelity. Conventional cones and dome tweeters are based on a directional moving coil principle whereas the monopole Neodymium Ribbon Tweeter radiates high frequencies in a full 180-degree radiation pattern. This dramatically increases the width of the sound spectrum in the higher tones and expands the sweet spot zone to deliver wide, crystal-clear, and natural sound even from compact audio systems.

Incredible Surround™

Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using

state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.

Treble and Bass Control

Treble and bass are equalizer features that control the high and low frequency sound levels of your audio respectively. Treble specifically regulates the amplification of the high tones in the music while bass controls the amplification level of the low tones. Using the up and down keys, the listener can conveniently place more or less emphasis on

the low and high tones, or leave treble and bass flat to playback music according to its original recorded setting. Treble and Bass Control lets you listen to your music the way you like it.

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

Rip your favorite CDs to MP3

Simply plug in your USB mass storage device to the USB port on Philips audio system and start recording your favorite music from CDs to your USB device or MP3 player - with one touch and no computer needed. So you can create your own MP3 files via direct MP3 digital recording.



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.



Specifications

Sound

- Sound enhancement: incredible surround, treble and bass control
- Output power: 2 x 75 W RMS

Loudspeakers

- Speaker drivers: 5.25" woofer, ribbon tweeter
- Loudspeaker enhancement: 2-way, speaker grilles detachable
- Speaker types: bass reflex speaker system

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD, USB flash drive
- Disc playback modes: fast forward/backward, repeat/one/all/program, repeat/shuffle/program
- Others: ID3-tag support
- Cassette deck technology: full logical
- Cassette Playback Modes: autoreverse, electronic speed control, full auto stop, tape counter
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, program play, repeat, shuffle, stop

Audio recording

- Recording media: tape
- Tape recording enhancement: automatic recording level, CD synchro start recording, one-touch recording

Tuner/Reception/Transmission

- Tuner bands: FM stereo, AM, MW
- Station presets: 40
- Antenna: FM antenna, MW antenna
- RDS: news, radio text, RDS clock set, station name
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug & play)

Connectivity

- Audio/Video output: Headphone (3.5mm)
- MP3 Link: 3.5mm stereo line in
- USB: USB host

Convenience

- Alarms: CD alarm, radio alarm, tape alarm, USB alarm
- Clock: on main display, sleep timer
- Loader type: motorised, tray
- Display enhancements: DIM mode
- Display type: VFD display

Accessories

- Cables/Connection: power cord
- Remote control: 32-key with 2xAA batteries
- Others: FM/MW antenna, Quick start guide
- User Manual: multi-languages
- Warranty: World Wide Guarantee booklet

Dimensions

- Gross weight: 11 kg
- Main speaker dimensions (W x D): 175 x 203 mm
- Main speaker height: 252 mm
- Main unit depth: 340 mm
- Packaging width: 495 mm
- Main unit height: 252 mm
- Packaging height: 396 mm
- Main unit width: 179 mm
- Packaging depth: 343 mm

Power

- Power supply: 50/60 Hz
- Power supply: 110 - 240 V

Green

- Eco Power standby: 1 W



Issue date 2014-02-05

Version: 1.0.3

12 NC: 8670 000 50399
EAN: 87 12581 46880 4

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com