



Philips  
Universal remote control

3-in-1 for TV/DVD/STB

SRU5130



## Full function replacement

Operates more than 1000 brands

This universal remote control is the perfect choice if you want maximum functionality for 3 devices out of a choice of 6, with optimal convenience. The natural fit shape ensures comfortable control!

### **Ideal replacement for your old remote**

- Control up to 3 devices out of a choice of 6
- Ready for use with Philips equipment

### **Great convenience**

- Ergonomic shape enables comfortable control
- Easy to use grouped functions
- Batteries are included for unwrap-and-zap

### **Quick and easy setup**

- Easy setup with fast key recognition
- For questions and assistance call our URC service line
- URC support service via dedicated website

# PHILIPS

# Specifications

## Convenience

- Supported devices: TV, DVD, VCR, CABLE, SAT, DVB-T
- TV functions: Programme up/down, Volume up/down, mute, Power/standby, Digit keys, AV selection, external, Menu Control, Colour/Brightness control, Teletext keys, Fast text keys, Previous programme, Sleep/timer, 16:9, Guide, info
- Teletext enhancements: Fast text
- DVD functions: Transport keys, System menu control, Disc menu control, Digit keys
- VCR functions: Transport keys (6), Showview, VCR plus, Menu Control
- Installation steps: 2
- Copy key function
- Language support: GB/F/D/NL/DK/S/N/FIN
- Number of keys: 42
- Pre-programmed for Philips
- Regulatory approvals: CE Mark
- Splash-proof
- SAT/CBL functions: Channel up/down, Digit keys, Favourites, Guide, info, Menu Control, Text functions, Volume up/down, mute

## Accessories

- Battery: Yes, 1.5 V Battery R03/AAA

## Infrared Capabilities

- Operating distance: 33 ft (10 m)
- Transmitting LEDs: 1
- Universal IR code database
- Number of brands in database: Over 1000

- Carrier frequency range: 24–55 kHz
- Transmission angle: 90 degree

## Power

- Battery lifetime: 12 months
- Number of batteries: 2
- Battery type: AAA

## Packaging Data

- 12NC: 908210006476
- EAN/UPC/GTIN: 87 10895 93590 6
- Height: 33 mm
- Length: 304 mm
- Width: 157 mm

## Outer Carton

- EAN: 87 12581 39681 7
- Number of consumer packages: 6
- Gross weight: 1.578 kg
- Outer carton (L x W x H): 30.3 x 15 x 17.2 cm
- Net weight: 0.696 kg
- Tare weight: 0.882 kg

## Packaging dimensions

- EAN: 87 12581 37689 5
- Number of products included: 1
- Packaging type: Blister
- Packaging dimensions (W x H x D): 15.7 x 30.4 x 3.4 cm
- Gross weight: 0.245 kg
- Net weight: 0.116 kg
- Tare weight: 0.129 kg

# Highlights

## 3 out of 6 remote

The controller provides the convenience of controlling 3 out of a choice of 6 home entertainment devices with one remote control. The remote can be easily programmed to control almost any brand of almost all audio/video equipment, using the on-board IR code database. One single remote to operate all your devices, without the hassle of searching for the right remote!

## Ergonomic design

The smooth rounded shape fits perfectly in your hand for natural, balanced operation. It looks great too!

## Fast key recognition

Fast key recognition helps to quickly and easily correct keys that are not working after installing the brand of your equipment on your remote. Just press the key for 5 seconds while pointing the remote at your device. Once the device reacts, you have fixed the key.

## Easy to use grouped functions

Easily grouped functions allow you to easily recognise the buttons you need to control a specific audio video device. All functions of the device are grouped together on the remote. Moreover the top part of the remote is made up of different colour parts (black, silver, aluminium etc.) as well as different key finishings (black, silver, matt, glossy etc.) to quickly identify which keys go together to control a specific audio video device.



Issue date 2017-04-04

Version: 3.0.6

12 NC: 8670 000 35193  
EAN: 87 12581 37689 5

© 2017 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)