

Philips  
Compact home theater  
system



CTS4000



## Seduced by design, surrounded by sound

with the all-in-one home cinema

Enjoy the magic of movies in tighter spaces with this compact cinema system. Featuring an integrated universal iPod dock, a built-in subwoofer and Cinema Sound it immerses you in sound and quality video with HDMI 1080p upscaling.

### Hear and see

- Built-in subwoofer for incredible bass without the wires
- Cinema Sound for a wider, immersive sound experience
- Fullsound™ to bring your MP3 music to life
- HDMI 1080p upscales to high definition for sharper pictures

### Live and connect

- Compact design that fits anywhere, entertains every time
- Built-in dock for convenient playback from your iPod/iPhone
- Plays multiple disc and media formats
- USB and MP3 Link to connect all portable devices

### Use

- HDMI digital output for easy connection with only one cable
- Stunning single unit for great sound without the clutter

**PHILIPS**  
sense and simplicity

# Highlights

## Built-in subwoofer

A built-in subwoofer provides all the low tones that are essential to a great listening experience - whether you are watching a movie or playing a music CD. The deepest bass notes come out rich and clear, ensuring sensational entertainment with the intensity and vim that was meant to be. Despite delivering a sound experience at full tilt, the built-in subwoofer carries with it none of the clutter - allowing you to savor complete entertainment while keeping your room completely fuss-free. Now enjoy both your room and the boom.

## Cinema Sound

Cinema Sound delivers dynamic sound from a single unit system, and an unbeatable listening experience in any sort of space. Using a carefully calculated mix of array processing, psychoacoustics and precise driver positioning,

Cinema Sound delivers a sound field that is significantly widened, providing the listener with immersive sound - absolutely clutter-free.

## FullSound™

Philips' innovative FullSound technology faithfully restores sonic details to compressed MP3 music, dramatically enriching and enhancing it, so you can experience CD music without any distortion. Based on an audio post-processing algorithm, FullSound combines Philips' renowned expertise in music reproduction with the power of the latest generation Digital Signal Processor (DSP). The result is fuller bass with more depth and impact, boosted voice and instrument clarity, and rich detail. Rediscover your compressed MP3 music in true-to-life sound that will touch your soul and move your feet.

## HDMI for simple AV connection

HDMI stands for High Definition Multimedia Interface. It is a direct digital connection that can carry digital HD video as well as digital multichannel audio. By eliminating the conversion to analog signals it delivers perfect picture and sound quality, completely free from noise. HDMI is fully backward-compatible with (Digital Video Interface) DVI.

## Built-in dock for iPod/iPhone

A built-in dock for iPod/iPhone lets you play movies, music and photos from your iPod/iPhone. What's more, you can charge and control the iPod/iPhone and browse through its contents on your TV screen - all with the home theater's remote. Doing away with cumbersome cables and connections, the integrated dock brings portable entertainment into your home - with absolute ease.



# Specifications

## Picture/Display

- Picture enhancement: High Def (720p, 1080i, 1080p), Video Upscaling(720p, 1080i/p)

## Sound

- Frequency response: 180 Hz ~ 18 kHz / +-3dB Hz
- Signal to noise ratio: > 60 dB (A-weighted)
- Sound Enhancement: Night Mode
- Sound System: Cinema Sound, Dolby Digital, DTS, MPEG2, Stereo
- Total Power (RMS): 50 W
- Equalizer settings: Action, Concert, Gaming, News, Rock, Classic, Party

## Connectivity

- Front / Side connections: Dock connector, Headphone output 3.5mm jack, Hi-Speed USB
- Rear Connections: HDMI output, Composite video (CVBS) output, MP3 Link, AUX in, 12 V DC in

## Video Playback

- Compression formats: DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, MPEG1, MPEG2, MPEG4, WMV
- Playback Media: CD-R/CD-RW, DVD+R/+RW, DVD-R/-RW, DVD-Video, Video CD/SVCD
- Video disc playback system: NTSC, PAL

## Audio Playback

- Compression format: Dolby Digital, DTS, MP3,

- MPEG2 Multichannel, PCM, WMA
- Playback Media: Audio CD, CD-R/RW, DVD+R/+RW, DVD-R/-RW, USB flash drive

## Still Picture Playback

- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate, Slideshow with music playback, Zoom
- Playback Media: CD-R/RW, DVD+R/+RW, DVD-R/-RW, USB flash drive

## Power

- Power consumption: 22 W
- Standby power consumption: < 1W
- Power supply: AC/DC Adapter, 100-240VAC, 50/60Hz

## Accessories

- Included accessories: HDMI cable, CVBS video cable, Audio Cable, MP3 Line-in cable, Remote Control, 2 x AAA Batteries, AC-DC Adapter, Quick start guide, World Wide Warranty leaflet

## Dimensions

- Packaging dimensions (W x H x D): 385 x 254 x 330 mm
- Product dimensions (W x H x D): 273 x 172 x 273 mm
- Product weight: 2.6 kg



Issue date 2012-01-13

Version: 5.2.8

12 NC: 8670 000 38746  
EAN: 87 12581 41044 5

© 2012 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)