

Philips
Micro music system

Bluetooth
100 W

BTM2185



Rich and powerful sound

Obsessed with sound

Listen to all your digital music from your Smartphone via Bluetooth. This Philips Micro system also plays MP3-CD and CD-R/RW, and features Bass Reflex speakers for powerful and dramatic bass.

Enjoy your music from multiple sources

- Stream music wirelessly via Bluetooth™ from your smartphone
- USB Direct for easy MP3 music playback
- Play MP3-CD, CD and CD-R/RW
- Audio-in for portable music playback

Enrich your sound experience

- Dome tweeter for detailed and natural sound
- Digital Sound Control
- Bass Reflex Speaker System delivers a powerful, deeper bass
- 100W maximum output power

Easy to use

- Motorised CD loader for convenient access
- Digital tuning with preset stations for extra convenience

PHILIPS

Highlights

Stream music via Bluetooth™



Bluetooth is a short range wireless communication technology that is both robust and energy-efficient. The technology allows easy wireless connection to iPod/iPhone/iPad or other Bluetooth devices, such as smartphones, tablets or even laptops. So you can easily enjoy your favourite music, sound from video or game wirelessly on this speaker.

USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.

Dome tweeter

Dome tweeters reproduce clear high and mid-range frequencies that enhance the overall sound clarity coming from the speakers. Delivering a harmonious blend of undistorted and uncoloured wide-ranging sound, they offer detailed vocal clarity and instrument tone purity, thereby balancing the overall sound when paired with a combination of woofers.

Audio-in



The Audio-in connectivity allows direct playback of Audio-in content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the Audio in is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set balanced, clear, powerful, warm and bright controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalising technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Specifications

Sound

- Sound enhancement: digital sound control
- Maximum output power (RMS): 100 W

Loudspeakers

- Loudspeaker types: Dome tweeter
- Main Speaker: 2-way, 4" woofer, Bass Reflex Speaker System

Audio playback

- Disc playback modes: fast forward/reverse, next/previous track search, repeat/shuffle/programme
- Playback media: CD, CD-R/RW, MP3-CD, USB flash drive
- USB Direct playback modes: fast reverse/fast forward, play/pause, previous/next, repeat, shuffle, stop

Tuner/Reception/Transmission

- Tuner bands: FM mono, FM stereo
- Station presets: 20
- Antenna: FM fixed pigtail antenna
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug and play)

Connectivity

- USB: USB host
- Audio in (3.5 mm)
- Bluetooth profiles: A2DP

Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm
- Clock: On main display, sleep timer
- Display type: LED display
- Loader type: tray

Accessories

- Included accessories: AC Power Cord, FM antenna, User Manual
- Remote control: 21-key remote

Dimensions

- Main unit width: 180 mm
- Main unit height: 121 mm
- Main unit depth: 239 mm
- Main speaker dimensions (W x D): 140 x 185 mm
- Main speaker height: 260 mm
- Packaging width: 224 mm
- Packaging height: 312 mm
- Packaging depth: 471 mm
- Gross weight: 6.7 kg
- Net weight: 5.61 kg

Power

- Power supply: 100-240 VAC, 50/60 Hz



Issue date 2015-08-04

Version: 1.0.3

12 NC: 8670 001 16899
EAN: 48 95185 60170 0

© 2015 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com