



Philips
Portable DVD Player

21.6cm (8.5") widescreen LCD

PET816



DVD and DivX® movies on the go

Sit back, relax and watch movies on the go on the 8.5" TFT LCD display of the Philips PET816. Enjoy DVD, DivX®, MPEG4 movies, MP3-CD and CD on the go. Admire your JPEG photos anytime, anyplace.

Immerse in AV entertainment on the go

- Play DVD, DVD+/-R and DVD+/-RW, (S)VCD, DivX® & MPEG4 movies
- Plays MP3-CD, CD and CD-RW music
- Share JPEG image files with Picture CD

For your viewing comfort

- 21.6 cm/8.5" widescreen LCD display for high quality viewing
- Enjoy movies in 16:9 widescreen format
- Built-in quality stereo speakers

For ultimate convenience

- Up to 2-hours playback with rechargeable battery*
- Car adaptor and handy remote control included
- Few buttons for simple and easy control

PHILIPS

Highlights

Play DVD, DivX and MPEG4

With DivX® support, you are able to enjoy DivX® encoded videos in the comfort of your living room. The DivX® media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, memory cards and DVD-video. DivX®

CDs can be played back on selected DVD players, DVD Recorders and Home Theater Systems.

MP3-CD, CD and CD-RW music

MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without

radically degrading their audio quality. A single CD can store up to 10 hours of music.

Share picture CD (JPEG)

Multi-format playability allows you to view images on the go and play most disc formats for maximum disc compatibility and viewing pleasure.



Specifications

Picture/Display

- Display screen type: LCD TFT
- Diagonal screen size (inch): 8.5 inch
- Resolution: 480(w)x234(H)x3(RGB)
- Brightness: 200 cd/m²
- LCD panel type: Anti-glare polarizer
- Contrast ratio (typical): 250:1
- Effective viewing area: 187.2x105.3mm
- Pixel pitch: 0.13 (V) x 0.245 (H)
- Response time (typical): 30 ms

Sound

- Output Power: 250mW RMS(built-in speakers)
- Output power (RMS): 10mW RMS(earphone)
- Signal to noise ratio: >80dB(earphone), >62dB(built-in speakers)

Video Playback

- Playback Media: DVD, Picture CD, SVCD, Video CD, DVD-R/-RW, MP3-CD, CD-R/CD-RW, DVD+R/+RW, CD
- Disc Playback Modes: A-B Repeat, Angle, Disc Menu, Fast Backward, Fast Forward, OSD, Repeat, Shuffle Play, Slow Backward, Slow Forward, Zoom
- Video disc playback system: NTSC, PAL
- Compression formats: Divx, MPEG4

Audio Playback

- Compression format: Dolby Digital, MP3
- MP3 bit rates: 32 - 320 kbps
- Playback Media: CD, CD-RW, MP3-CD, CD-R
- File systems supported: ISO-9660, Joliet

Connectivity

- DC in: 9V
- Headphone jack: 3.5mm Stereo Headphone
- AV output: Composite (CVBS) x1

Convenience

- Battery charging indication
- Shock proof

Accessories

- AC/DC Adaptor: DC-IN 9V, 110-240v, 50/60Hz
- Car kit: cigarette outlet adaptor, 12vDC
- Remote control: AY5510 slim remote
- Cables: 1 x AV Cables
- User Manual: Simplified Chinese / English

Power

- Battery Type: Built-in battery

Dimensions

- Master carton dimensions: 284 x 272 x 262 mm
- Master carton quantity: 3
- Master carton weight: 4.77 kg
- Packaging dimensions (W x H x D): 274 x 254 x 84 mm
- Packaging type: D-box
- Product dimensions (W x H x D): 210 x 39 x 178 mm
- Product weight: 1.1 kg



Issue date 2014-02-07

Version: 1.0.3

12 NC: 8670 000 40647
EAN: 87 12581 43040 5

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com