



Philips  
Clock Radio

AJ5100

## Digital radio with crystal clear sound quality

With the sleek and portable AJ5100, you can now enjoy CD-quality music from Digital Audio Broadcasting (DAB). Easy-to-use functions such as the 5 one-touch buttons allow you to access your favourite stations instantly.

### **Superb performance in compact design**

- Interference-free DAB radio
- DAB and FM preset stations
- Bass Reflex speakers deliver a powerful, deeper bass

### **Easy to use**

- Sleep timer helps you to drop off to your favourite music
- Backlit LCD display
- Mains or battery operated

**PHILIPS**  
sense and simplicity

# Specifications

## Tuner/reception/transmission

- DAB: Band III, Info display, Smart Scan, Menu
- Tuner Bands: FM
- Station presets: 20
- Auto digital tuning
- Antenna: FM Antenna

## Sound

- Loudspeaker types: Bass Reflex Speaker System
- Output power (RMS): 2 x 1.5 W
- Sound System: Stereo
- Speaker diameter: 3"
- Volume Control: Volume Control up/down

## Loudspeakers

- Built-in speakers: 2

## Connectivity

- Headphones: 3.5 mm
- DC in: 9 V

## Convenience

- Display Type: LCD

- Backlight
- Alarms: Sleep timer
- Backlight colour: Blue

## Power

- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 6
- Battery type: UM2, R14

## Accessories

- AC/DC adapter
- Included Accessories: AC Power Lead, AC-DC Adapter, Quick install guide, User manual, Warranty certificate

## Dimensions

- Packaging dimensions (W x H x D): 293 x 251 x 180 mm
- Product dimensions (W x H x D): 269 x 212 x 130 mm
- Weight: 2.4 kg
- Weight incl. Packaging: 2.6 kg



# Highlights

## Interference-free DAB radio

DAB (Digital Audio Broadcasting) digital radio is, in addition to FM analogue transmission, a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in crystal clear, crackle-free sound quality. The technology allows the receiver to lock onto the strongest signal it can find. With DAB digital stations there are no frequencies to remember and sets are tuned by station name, so there is no returning on the move.

## DAB and FM preset stations

DAB and FM preset stations

## Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

## Sleep Timer

Sleep timer lets you decide how long you want to listen to music, or a radio station of your choice, before falling asleep. Simply set a time limit (up to 1 hour) and choose a CD or radio station to listen to while you drift off to sleep. The set will continue to play for the selected duration and then automatically switch to a power-efficient and silent stand-by mode. Sleep Timer lets you fall asleep to your favourite CD or radio DJ without counting sheep, or worrying about wasting electricity.

## backlit LCD display

Backlit LCD display

## Mains or battery operated

Mains or battery operated



Issue date 2011-09-09

Version: 2.2.9

12 NC: 9073 101 02634  
EAN: 87 10895 96614 6

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)