



Philips  
Notebook webcam

Easy



SPC530NC

## Webcam easy

Keep in touch

1.3 MP resolution, 3 x digital zoom and noise reduction. Webcam easy SPC530 gives you smooth images and clear sound so that video chatting time becomes high-quality time. With plug and play, staying in touch with loved ones has never been easier.

### Natural video at higher resolutions

- 1.3 Mega Pixels resolution (interp.) for enhanced image quality
- Smooth image with 30 frames per second video
- 3 x digital zoom for superb close-ups
- Face tracking automatically follows your face
- Rotating body to aim the camera wherever you want

### Clear and natural voice

- Built-in digital microphone for quality sound
- Noise reduction enhances clarity of speech

### Easy as 1-2-3

- Easy set-up and use
- Compatible with all instant messaging services
- Take, archive and manage images with VLounge
- Snapshot button lets you take great instant photos
- Mounts securely on any monitor, laptop or desk



**PHILIPS**  
sense and simplicity

# Specifications

## Mechanics

- Sensor: VGA CMOS
- Lens maximum aperture: F: 2.6
- Lens view angle: 50 degrees
- Lens construction: 3 elements
- White balance: 2600 - 7600 K
- Minimum illuminance: < 5 lux
- Data format: YUY2, MJPEG
- Colour depth: 24 bit

## Resolution

- Video resolution: VGA
- Photo resolution: VGA
- Interpolated video resolution: 1.3 MP
- Interpolated photo resolution: 1.3 MP
- Maximum frame rate: 30 fps

## Audio

- Microphone: Built-in microphone
- Noise reduction

## Additional features

- Digital zoom: 3 x
- Face tracking
- Snapshot button
- On/off activity LED

## Software

- V Lounge: Premium
- Add video to: Skype, Windows Live Messenger, Yahoo! Messenger, AOL Instant Messenger

## System Requirements

- Operating System: Microsoft Windows XP (SP2), Microsoft Windows Vista



- Processor: Pentium III 850 MHz or higher
- RAM memory: 256 MB RAM
- Hard disk space: 200 MB
- USB: Free USB port
- CD-ROM or DVD-ROM Drive

## Connectivity

- Cable length: 1.5 metre
- Interfacing: USB 1.1, USB 2.0
- USB video class: UVC
- Power: Supplied via USB cable

## Product dimensions

- Product dimensions (W x H x D): 3.7 x 5 x 1.7 cm
- Product dimensions with stand (W x H x D): 3.7 x 7.1 x 6.2 cm
- Weight (with stand): 0.0905 kg

## Packaging dimensions

- EAN: 87 12581 39595 7
- Number of products included: 1
- Packaging type: Carton
- Packaging dimensions (W x H x D): 19.2 x 18.6 x 9.2 cm
- Net weight: 0.0905 kg
- Gross weight: 0.29 kg
- Tare weight: 0.1995 kg

## Outer Carton

- EAN: 87 12581 42359 9
- Number of consumer packages: 6
- Outer carton (L x W x H): 40 x 30 x 22 cm
- Net weight: 0.543 kg
- Gross weight: 2.5 kg
- Tare weight: 1.957 kg

# Highlights

## 1.3 Mega Pixels (interpolated)

Your webcam gives you 1.3 Mega Pixels (interpolated) for both video and photo resolution. So, you can use it to take high-quality photos that still look great when printed as larger-sized images.

## 30 frames per second video

Sit back and enjoy superior viewing with 30 frames per second video. This gives you smoother video images and a better all-round video chatting experience.

## 3 x digital zoom

Zoom in and out to get the perfect framing for any image. You control the zoom entirely via the on-screen interface while you are looking at the image so you can adjust it perfectly.

## Automatic face tracking

The state-of-the-art camera software automatically detects your face and moves the lens to follow you as you move. You stay in the centre of the image even if you move during a video conference. It gives you the freedom to express yourself and converse naturally.

## Rotating body

Enjoy webcam-freedom with a clever rotating body that lets you aim the camera wherever you want. Just twist the camera in any direction to film anywhere in your room without moving the webcam at all.

## Built-in digital microphone

The built-in digital microphone allows you to talk naturally and freely or to add sound to a video clip recording.

## Noise reduction

This superb noise reduction technology reduces background noise, and it enhances clarity of speech in both quiet and noisy environments.

## Easy set-up and use

Setting-up and using your webcam is easy as 1-2-3. 1. Install software 2. Plug in camera 3. Video call instantly

## Compatible with all services

The webcam and its software have been designed with all instant messaging services in mind. Add video to Skype, Windows Live Messenger, Yahoo! Messenger, AOL Instant Messenger and other services.

## V Lounge software

Software for capturing, managing and archiving snapshots and video clips in a very convenient way. With just a couple of mouse clicks you will be able to create and send Video mails. This software package gives you all you need to take full advantage of your Philips webcam.

## Snapshot button

With just one press of this button, your webcam takes a picture automatically. It's a fun way to share your pictures by adding them to e-mails, webpages or documents.

## Mounts securely

The multifunctional stand makes it easy for you to mount the webcam securely on top of any monitor, laptop or desk. This design is especially secure and won't move or fall when you're in the middle of a conversation.



Issue date 2011-02-18

Version: 3.0.8

12 NC: 8670 000 37146  
EAN: 87 12581 39595 7

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)