

Philips  
Multimedia Speakers 2.1



SPA9300



## Stunning sound and style

The superlative 100W MPO experience from the SPA9300 speaker system is yours thanks to quality Mylar tweeters and a separate woofer with 6-layer driver coils to deepen every beat. Stylish stainless steel enclosure enhances the performance.

### Ultimate bass performance

- Dynamic bass boost - hear the deepest, richest bass
- Bass boost technology with level control
- 6-layer Woofer driver - extra muscle to boost the bass

### Connect to all your gear

- Perfect for MP3, PC, TV, CD & more
- Unique direct MP3 input via your RC

### Multimedia sound sensation

- Tweeters made of Mylar material for high definition sound

### Contemporary design

- Stainless steel design & stand - high performance with style

# PHILIPS

# Specifications

## Sound

- Bass enhancement: Dynamic Bass Boost, Bass reflex
- Bass optimization
- Frequency response: 35 - 20.000 Hz
- Loudspeaker Enhancement: Magnetic Shielded LSB
- Music Power: 100 W
- Output power (RMS): Per satellite: 10 W; subwoofer 30W
- Sound Enhancement: Balance
- Volume Control: Analogue Volume Control

## Loudspeakers

- Aluminium cone
- CD tweeter
- Loudspeaker Enhancement: Magnetic Shielded LSB
- Mylar dome
- Neodymium magnet system
- Satellite speaker drivers: 2x 50mm
- Subwoofer driver: 8" high efficiency woofer
- Bass level control: On subwoofer

## Connectivity

- Audio input for data: Stereo Audio (3.5 mm jack) 1x
- Cable length: 2 m
- Connector: 3.5 mm stereo
- Power: AC 220V 50Hz

## Convenience

- Power on indication
- Remote control: -Volume control and AUX input

(p.e. MP3) -Power on/off indication

## Power

- Power LED indicator: Blue

## Packaging content

- Subwoofer
- Number of satellites: 2
- 3.5 mm stereo line cable
- Quick installation guide
- Remote Control: Wired
- Warranty card

## Packaging Data

- 12NC: 908210005133
- EAN/UPC/GTIN: 8710895 932066
- Gross weight: 7.49 kg
- Height: 323 mm
- Length: 458 mm
- Width: 325 mm
- Quantity: 1
- Tare weight: 1.09 kg

## Outer Carton

- Quantity: 3
- EAN/UPC/GTIN: 8710895945783
- Tare weight: 1.4 kg
- Gross weight: 23.87 kg
- Length: 995 mm
- Width: 478 mm
- Height: 359 mm
- 12NC: 908210005133

# Highlights

## Dynamic bass boost

Innovative technology delivers unbelievably deep, rich bass from compact speakers. Dynamic bass boost emphasizes the bass content of the music throughout the range of volume settings from low to high – at the touch of a button!

## Bass with level control

Unique subwoofer design produces a much deeper, richer bass. You also have the possibility to set the bass level to your choice.

## 6-layer Woofer driver

Strengthened driver coils boost the bass to the max and deepen every beat.

## Perfect for MP3, PC, TV & more

Connect your speakers to all your gear. A great way to listen to your MP3 player, PC, TV, CD, DVD and all your multimedia stuff.

## MP3 input via your RC

Thanks to the unique direct MP3 input on the remote control you can easily listen to your MP3 player. Simply connect the audio output of your MP3 player to the 3.5 mm jack on the remote control and enjoy your music.

## Mylar tweeters

The unique Mylar material of the dual-form dome tweeters ensure incredible sound definition. Music comes to life and movies sound like they were meant to, as the full range of high frequencies is perfectly reproduced.

## Stainless steel design & stand

The stylish housing and stand of the speakers are made of stainless steel to increase the durability and the visual performance of the product. A stylish way to enhance the superlative audio performance of your speakers.



Issue date 2013-05-10

Version: 4.0.9

12 NC: 9082 100 05133  
EAN: 87 10895 93206 6

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)