



Philips  
5.1 Home theater

420W RMS power

DVD playback

**HTS3276**

## Spectacular surround sound with deep powerful bass

High definition pictures and surround sound delivered by this system provide amazing home entertainment. Enjoy crisp pictures with 1080p HDMI upscaling, and playback from USB drives, portable media players and virtually any sort of disc.

### **Bring audio and video to life**

- DTS, Dolby Digital and Pro Logic II surround sound
- Advanced Class D Amplifier for compact, powerful sound
- HDMI 1080p upscales to high definition for sharper pictures
- Karaoke Scoring for fun and exciting song contests at home

### **Connect and enjoy multiple sources**

- Hi-Speed USB 2.0 Link plays video/music from USB flash drive
- Multiple digital inputs for quality sound from other sources

### **Easy to set up and use**

- EasyLink to control all HDMI CEC devices via a single remote

### **Play all your movies and music**

- DivX Ultra Certified for enhanced playback of DivX videos
- Plays WMV, DivX, WMA, MP3 and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW, DVD+R DL

**PHILIPS**  
sense and simplicity

# Highlights

## DTS, DolbyDigital, ProLogic II

A built-in DTS and Dolby Digital decoder eliminates the need for an external decoder by processing all six channels of audio information to provide a surround sound experience and an astoundingly natural sense of ambience and dynamic realism. Dolby Pro Logic II provides five channels of surround processing from any stereo source.

## Advanced Class D Amplifier

Advanced Class D Amplifier for compact, powerful sound

## HDMI 1080p

HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multichannel audio, without conversions to analog - delivering perfect picture and sound quality, completely free from noise.

## Hi-Speed USB 2.0 Link

The Universal Serial Bus or USB is a protocol standard that is conveniently used to link PCs, peripherals and consumer electronic equipment. Hi-Speed USB devices have a data transfer rate of up to 480 Mbps - up from the 12 Mbps in original USB ones. With Hi-Speed USB 2.0 Link, all you have to do is plug in your USB device, select the movie, music or photo and play away.

## Karaoke Scoring

Add a dash of fun to your Karaoke sessions with Karaoke Scoring. Allow your performance to be judged for further improvement, or for friendly competitions. Karaoke Scoring automatically rates your singing and gives you a humorous picture that is tied to how well you did. The fun never ends.

## EasyLink

EasyLink lets you control multiple devices with one remote. It uses HDMI CEC industry-standard protocol to share functionality between devices through the HDMI cable. With one touch of a button, you can operate all your connected HDMI CEC enabled equipment simultaneously. Functions like standby and play can now be carried out with absolute ease.

## DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

## Plays it all

Play virtually any media format you want - whether they be WMV, DivX, MP3s or JPEGs. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system - in the comfort of your living room.

## Plays it all

Play virtually any disc you want - whether they be CDs, (S)VCDs, DVDs, DVD+R, DVD-R, DVD+RW, DVD-RW or DVD+R DL. Experience unbeatable flexibility and the convenience of playing all your discs on the one device.



# Specifications

## Picture/Display

- D/A converter: 12bit, 108MHz
- Picture enhancement: Progressive scan

## Sound

- Total Power (RMS): 420 W
- Output power (RMS): 4x55W, 2x100W
- D/A converter: 24 bit, 192 kHz
- Frequency response: 40-20000 Hz
- Signal to noise ratio: > 60 dB
- Sound System: Dolby Digital, Dolby Prologic II, DTS, Stereo
- Equalizer settings: Action, Classic, Concert, Drama, Gaming, Lounge, Rock, Sports
- Sound Enhancement: Class "D" Digital Amplifier, Night Mode

## Video Playback

- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra
- Playback Media: DVD-Video, DVD+R/+RW, DVD-R/-RW, Video CD/SVCD, CD-R/CD-RW
- Video disc playback system: NTSC, PAL

## Audio Playback

- Compression format: MP3, WMA
- Playback Media: DVD+R/+RW, DVD-R/-RW
- MP3 bit rates: 32-256 kbps and VBR

## Still Picture Playback

- Picture Compression Format: JPEG
- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, USB flash drive
- Picture Enhancement: Rotate, Zoom, Slideshow with music playback

## Tuner/Reception/Transmission

- Tuner Bands: FM

## Connectivity

- Rear Connections: Component Video output, Composite video (CVBS) output, AUX in, FM Antenna, Easy-Fit Speaker Connectors, HDMI output, Digital coaxial in, Digital optical out
- Front / Side connections: Microphone input 3.5mm

jack, MP3 Line-in, Hi-Speed USB

## Power

- Power supply: 120/230VAC, 50/60Hz
- Standby power consumption: < 1 W
- Power consumption: 80 W

## Loudspeakers

- Satellite speaker drivers: 3" full range woofer
- Satellite speaker impedance: 8 ohm
- Satellite speaker freq range: 150-20000 Hz
- Center speaker drivers: 3" full range woofer
- Center speaker impedance: 4 ohm
- Center freq range: 150-20000 Hz
- Subwoofer driver: 6.5" high efficiency woofer
- Subwoofer type: Passive
- Subwoofer impedance: 4 ohm
- Subwoofer freq range: 40-150 Hz

## Accessories

- Included accessories: Remote Control, 2 x AAA Batteries, CVBS video cable, FM antenna, Quick start guide, User Manual, World Wide Warranty leaflet, Power cord

## Dimensions

- Set dimensions (W x H x D): 360 x 57 x 331 mm
- Set weight: 2.87 kg
- Center speaker dimensions (W x H x D): 244 x 103 x 74 mm
- Center Speaker Weight: 0.849 kg
- Subwoofer dimensions (W x H x D): 163 x 363 x 369 mm
- Subwoofer Weight: 4.703 kg
- Packaging dimensions (W x H x D): 962 x 409 x 444 mm
- Weight incl. Packaging: 20.7 kg
- Front Speaker Depth: 264 mm
- Front Speaker Height: 1199 mm
- Front Speaker Weight: 3.6 kg
- Front Speaker Width: 262 mm
- Rear Speaker Depth: 71 mm
- Rear Speaker Height: 203 mm
- Rear Speaker Weight: 0.554 kg
- Rear Speaker Width: 103 mm



Issue date 2011-06-06

Version: 2.1.7

12 NC: 8670 000 48773  
EAN: 87 12581 45932 1

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)