

Philips  
Portable DVD Player

17.8 cm/7" widescreen LCD



PET702



## Home and away DVD

with adaptor for in car use

Sit back, relax and watch movies on the go on the 7" TFT LCD display of the Philips PET702. Enjoy your favorite DVD movies, MP3-CD and CD music, or admire your JPEG photos anytime, anyplace.

### Immerse in AV entertainment on the go

- Play DVD, DVD+/-R, DVD+/-RW and (S)VCD
- Plays MP3-CD, CD and CD-RW music
- Share JPEG image files with Picture CD

### For your viewing comfort

- 17.8 cm (7") TFT color LCD display for high quality viewing
- Enjoy movies in 16:9 widescreen format
- Built-in quality stereo speakers

### For ultimate convenience

- Smart Car Mount for ease-of-use
- Car adaptor and handy remote control included
- Few buttons for simple and easy control
- Up to 2-hours playback with rechargeable battery\*

# PHILIPS

# Specifications

## Picture/Display

- Display screen type: LCD TFT
- LCD panel type: Anti-glare polarizer
- Diagonal screen size (inch): 7 inch
- Resolution: 480(w)x234(H)x3(RGB)
- Brightness: 200 cd/m<sup>2</sup>
- Contrast ratio (typical): 250:1
- Effective viewing area: 154.1x86.6mm
- Pixel pitch: 0.107(w)x0.370(H)mm
- Response time (typical): 30 ms

## Sound

- Output Power: 250mW RMS(built-in speakers)
- Output power (RMS): 10mW RMS(earphone)
- Signal to noise ratio: >80dB(earphone), >62dB(built-in speakers)

## Video Playback

- Playback Media: DVD, Picture CD, SVCD, Video CD, DVD-R/-RW, MP3-CD, CD-R/CD-RW, DVD+R/+RW, CD
- Disc Playback Modes: A-B Repeat, Angle, Disc Menu, Fast Backward, Fast Forward, OSD, Repeat, Shuffle Play, Slow Backward, Slow Forward, Zoom
- Video disc playback system: NTSC, PAL

## Audio Playback

- Compression format: Dolby Digital, MP3
- MP3 bit rates: 32 - 320 kbps
- Playback Media: CD, CD-RW, MP3-CD, CD-R
- File systems supported: ISO-9660, Joliet

## Connectivity

- DC in: 9V
- Headphone jack: 3.5mm Stereo Headphone
- AV output: Composite (CVBS) x1

## Convenience

- Battery charging indication
- Shock proof

## Accessories

- AC/DC Adaptor: DC-IN 9V, 110-240v, 50/60Hz
- Car kit: cigarette outlet adaptor, 12vDC
- Remote control: AY5510 slim remote
- Cables: 1 x AV Cables
- User Manual: Spanish / Portuguese
- Smart car mount: x 1

## Power

- Battery Type: Built-in battery

## Dimensions

- Master carton dimensions: 260 x 272 x 227 mm
- Master carton quantity: 3
- Master carton weight: 5.3 kg
- Packaging type: D-box
- Packaging dimensions (W x H x D): 250 x 255 x 70 mm
- Product dimensions (W x H x D): 197 x 37 x 153 mm
- Product weight: 0.71 kg

# Highlights

## MP3-CD, CD and CD-RW music

MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. A single CD can store up to 10 hours of music.

## Share picture CD (JPEG)

Multi-format playability allows you to view images on the go and play most disc formats for maximum disc compatibility and viewing pleasure.

## Smart Car Mount

To enjoy entertainment on the go, why not bring your portable DVD player from home on the road with you? A unique Car Mount system ensures ease-of-use, with a quick-release arm that facilitates easy removal of the player when not in use. You can bring the portable DVD player with you, leaving just the Mount behind in the car.



Issue date 2014-02-06

Version: 2.0.4

12 NC: 8670 000 39716  
EAN: 87 12581 42281 3

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Avoid extensive use of the set in a volume higher than 85 decibel  
because this may damage your hearing.